



## Certified Capability List

This Capability List is based on a certification session performed by the *TALQ Certification Tool (v2.5.0-online.4)* on 2023-05-30 11:27:27.464 +0200.

The Capability List is a consolidated list of TALQ features which are implemented in a product.

The tool has successfully performed 34 tests.

## Product details

**Product Name** AndrosLive

**Company** UMPI srl

**Type** GATEWAY

**Notes**

**Generated on** 2023-05-30 11:27:27.464 +0200

**Supported profiles** • Lighting

**API version certified:** 2.5.0

**Certification performed by app version:** 2.5.0-online.4

## Capability list

### Security

Enabled ✓

# Functions

## Basic

The Basic function describes the properties related to the physical asset to which the logical device is associated, such as identification (assetId) and location information.

### Attributes

#	Attribute	Description
✓	displayName	Display name of the asset.
✓	serial	Serial number of the device.
✓	swVersion	Software version installed on the device.
✓	currentTime	Current time of the device defined as local time with time zone designator. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TimeFunction.currentTime instead.]

### Events

#	Event type	Description
✓	deviceReset	The physical device containing the logical device was reset

## Gateway

The Gateway function includes the necessary attributes to enable the communication between the CMS and the Gateway according to the TALQ Specification.

### Attributes

#	Attribute	Description
✓	cmsUri	Base URI for TALQ communication that allows the Gateway to access the CMS. Must be an absolute URI. Other URI's for accessing CMS can be relative to this base.
✓	cmsAddress	CMS UUID address
✓	gatewayUri	Base URI for TALQ communication that allows the CMS to access the Gateway. Must be an absolute URI. Other URI's for accessing Gateway can be relative to this base.
✓	gatewayAddress	Gateway UUID address

✓ retryPeriod	Time duration before the Gateway retransmits a message for which expected response has not been received. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new GatewayFunction.gatewayRetryPeriod instead.]
✓ crlUrn	URI where the Gateway can obtain the Certification Revocation List (CRL).
✓ vendor	Vendor identification.

## Lamp Actuator

The Lamp Actuator function includes attributes related to lighting control and it represents the smallest unit for control purposes. In practice, however, a Lamp Actuator function can control combinations of several lamps and control gear but all in the same way, as if they are all one individual unit.

### Attributes

#	Attribute	Description
✓	lampTypeId	TALQ Address of an existing lampType.
✓	defaultLightState	Sets the default light output for the lamp actuator. This shall be applicable if no other command is active. This attribute shall be set to 100% as default value.
✓	targetLightCommand	Latest command for the lamp actuator.
✓	feedbackLightCommand	This attribute reflects the command in effect and it might deviate from the actualLightState due to propagation time or due to internal ODN specific mechanisms to handle the priority of the requests.
✓	actualLightState	This attribute should reflect the physical state of the light source as much as possible, including factors such as CLO. It may be calculated or measured, depending on the specific ODN implementation, which is outside the scope of this specification.
✓	calendarID	TALQ Address of the calendar controlling this lamp actuator. If this attribute is empty, the behavior shall be determined by the ODN. If the attribute is invalid, the ODN shall trigger a generic invalid address event and the behavior shall be determined by the ODN.

### Events

#	Event type	Description
---	------------	-------------

✓ lightStateChange Light state has changed

## Lamp Monitor

The Lamp Monitor function enables monitoring of lamp parameters. A Lamp Monitor function should be associated with a specific lamp/control gear combination. Multiple lamp monitor functions may be implemented by a single device.

### Attributes

#	Attribute	Description
✓	lampTypeId	TALQ Address of an existing lamp type. If not set to a valid value, this shall be the lamp type used in the lamp actuator. If this attribute is not supported in the implementation, the lamp monitor shall use the lamp type specified in the corresponding lamp actuator.
✓	numberOfLamps	Number of lamps being monitored by the lamp monitor function.
✓	supplyVoltage	RMS supply volts when supplyType is AC, supply voltage (V) when supplyType is DC.
✓	supplyCurrent	RMS supply current (A) when supplyType is AC, supply current (A) when supplyType is DC.
✓	activePower	Active power.
✓	powerFactor	Active power/Apparent power.
✓	powerFactorSense	Phase sense of power factor.
✓	activeEnergy	Cumulative active energy (since installation or counter reset).
✓	lampFailure	The lamp is not operating as it is supposed to (e.g. the lamp is broken). This event shall be used to detect a situation where the lamp (or LED module(s)) should be lit, but produce no light. This could be detected by the current flowing or power consumed.
✓	dimmingFailure	The lamp is not dimming as it is supposed to (e.g. the driver is not connected properly). This event shall be used to detect a situation where the lamp (or LED module(s)) is lighting at a dimming level which is different from the expected dimming level, taking into account the programmed (or manual) level as well any correction (e.g. virtual power, constant light output).
✓	powerFactorTooLow	The power factor is below powerFactorThreshold.

## Events

#	Event type	Description
✓	lampFailure	The lamp is not operating as it is supposed to (e.g. the lamp is broken). This event shall be used to detect a situation where the lamp (or LED module(s)) should be lit, but produce no light. This could be detected by the current flowing or power consumed.

## Location Sensor\*

The Location Sensor Function is used to indicate that an object has changed position attributes configurable by the CMS or based on internal setup of the vendor. For example, a specific location (latitude, longitude) of a device could be defined by the vendor. If the device is equipped with a GPS, it could send a specific event indicating that its position is different to the one defined by the CMS. We might also want to let the configuration to the vendor itself and simply define events notifying the CMS that the default configuration has changed. For example, a garbage bin could have its location defined based on a sensor placed on the floor. If the bin is not above this sensor, the vendor will trigger an event. In this last case, the CMS does not need to configure anything.

## Attributes

#	Attribute	Description
✓	location	Location of the device

## Events

#	Event type	Description
✓	locationChanged	Triggered when the difference between location and expectedLocation is above locationChangedThreshold

## Time\*

The Time function includes attributes related to generic control and it represents the smallest unit for control purposes.

## Attributes

#	Attribute	Description
✓	timeZone	Time zone of the device. Time zone may be expressed in two formats. where is a time zone as defined in the zone.tab of the IANA timezone database [IANA]; and stdoffset[dst[offset][,start[/time],end[/time]]] as defined by the Open Group for posix systems [POSIX].
✓	currentTime	Current time of the device defined as local time with time zone designator.

## Events

#	Event type	Description
---	------------	-------------

## Services

### Configuration Service

The TALQ Configuration Service enables discovery and configuration of devices and services

#### Options

#	Option	Value	Description
✓	commissioningSupported*		This ODN can support commissioning from the CMS side.
✓	devicesPaginationSupported*		This ODN can support pagination of devices.

### Control Service

The Control service describes the mechanisms to operate the actuator functions in order to enable schedule based and override control

#### Options

#	Option	Value	Description
✓	supportedTypes	<ul style="list-style-type: none"> <li>AbsoluteActivePeriod</li> <li>AstroClockActivePeriod</li> <li>AstroClockTimeControl*</li> </ul>	Control Program and calendar options supported are defined by announcing support for the given modes
✓	maximumCalendars		Maximum number of calendars supported
✓	maximumPrograms		Maximum number of control programs supported

✓ maxProgramsPerCalendar	Maximum number of control programs per calendar
✓ maxSwitchPointsPerProgram	Maximum number of switching points per control program
✓ maxActivePeriodsPerProgram	Maximum number of active periods per control program
✓ programSecondsSupported*	Indicates whether the field of seconds is supported in programs.

## Events

#	Event Type	Description
✓	invalidCalendar	An invalid calendar has been provided by the CMS to the ODN
✓	invalidProgram	A control program has been provided by the CMS, which cannot be implemented by the ODN

## Data Collection Service

The TALQ Data Collection Service is a provision to configure how ODN measurements, status information and events are logged, and when or under what conditions the logged data is transferred to the CMS

## Options

#	Option	Value	Description
✓	supportedModes	<ul style="list-style-type: none"> <li>VendorRecordingMode</li> <li>EventRecordingMode</li> <li>ImmediateReportingMode</li> </ul>	Recording and Reporting modes supported

## Events

#	Event Type	Description
✓	invalidLoggerConfig	The CMS has provided a data logger configuration that cannot be implemented by the ODN

## On Demand Data Request Service

This service provides the mechanism to access attributes in the logical devices by requesting attribute values from the ODN

## Objects

### Event log data

Event log data contains a single event, with eventType and value, in each single log entry. It also includes information about whether the log denotes the start or end of the event. Furthermore additional information can be added with the info attribute.

#### Properties

#	Property	Description
✓	eventType	Identifier of event reported
✓	srcAddress	Address of Logical device or function within a logical device which is the source of the event or to which this event applies

### Command

A command defines a type of control action that can be applied to a function. Commands can be generated by a manual override action or by a control program.


#### Properties

#	Property	Description
✓	state	Light state to be applied to the lamp actuator
✓	cmsRefId	CMS reference, which can be used for data logging. The cmsRefId in a Command is a free text to be used by the CMS for any purpose, e.g: to differentiate contexts. It is a token that allows the CMS to match client requests to the original notification.



\*: The Certification Test Tool is designed to provide a high level of confidence that complementary systems can communicate successfully. As both the protocol and the test tool evolve, all mandatory and other core tests are confirmed by comparison with real-life scenarios (plug-fest or similar). Some tests of optional and more peripheral features may not yet have been confirmed in this way; such features are identified with an asterisk (\*).

This Capability List is based on a certification session performed by the TALQ Certification Tool (v2.5.0-online.4) on 2023-05-30 11:27:27.464 +0200.

 and **TALQ** are trademarks owned by the TALQ Consortium.

© TALQ Consortium

