



Certified Capability List

This Capability List is based on a certification session performed by the *TALQ Certification Tool (v2.7.0-online.1)* on 2026-02-27 19:56:47.040 +0800.

The Capability List is a consolidated list of TALQ features which are implemented in a product.

The tool has successfully performed 48 tests.

Product details

Product Name Longjoin Gateway V1.0

Company longjoin

Type GATEWAY

Notes Longjoin Gateway is used for smart lighting applications. It can support different standard interfaces, communication methods and functions by optional configuration. For example, NEMA/ZHAGA/Wiring, WAN/4G/NB-IOT/Zigbee/LoRaWAN/PLC-IOT, 0-10/DALI/PWM, GPS, light sensing, zero-crossing switch, electrical metering, motion detection, pre-lighting linkage, tilt detection, temperature detection, under-voltage/over-voltage/over-current alarm and protection, abnormal brightness of lamps alarm, etc.

Generated on 2026-02-27 19:56:47.040 +0800

- Supported profiles**
- Lighting
 - Lighting Asset Management

API version certified: 2.7.0

Certification performed by app version: 2.7.0-online.1

Functional tests

The Functional Tests help customers understand the capabilities of a TALQ-certified product. All functional test cases are presented to provide comprehensive context, and successful completion of each test is indicated with a tick mark. Each Functional Test is related to a set of required TALQ technical test cases.

Configuring

1 of 11

Connect to CMS and announce light point control capabilities

The Gateway successfully connects to a CMS and transmits its capabilities (i.e. supported features) for light point configuration, control, programming and monitoring. **CONFIG-1**

Connect to CMS and announce cabinet control capabilities

The Gateway successfully connects to a CMS and transmits its capabilities (i.e. supported features) for lighting cabinet controller configuration, control, programming, and monitoring. **CONFIG-2**

Connect to CMS and announce dynamic sensor-based lighting capabilities

The Gateway successfully connects to a CMS and transmits its capabilities (i.e. supported features) for dynamic lighting based on sensor. **CONFIG-3**

Announce the list of light point controllers on the network ✓

The Gateway transmits all the devices (light point controllers, cabinet controller and any other type of device) that are known on the network, to the CMS together with their configuration and asset information. **CONFIG-4**

Configure light point controllers electrical alarm thresholds from the CMS

The Gateway can receive the electrical alarm thresholds from the CMS and assign them to selected light point controllers. This includes Lamp Voltage Too High/Low, Lamp Current Too High/Low, Active Power Too High/Low and Power Factor Too Low. **CONFIG-5**

Configure the cabinet controllers alarm thresholds from the CMS

The Gateway can receive the electrical alarm thresholds from the CMS and assign them **CONFIG-6** to selected cabinet controllers.

Configure the light point controllers' parameters from the CMS

The Gateway can receive configuration parameters from the CMS and assign them to **CONFIG-7** selected light point controllers.

Create and change group of light point controllers from the CMS

The Gateway can handle a command from the CMS to create or to change a group of **CONFIG-8** light point controllers to assign them a control program.

Change the sampling frequency for telemetry measurements

The Gateway can change the sampling of telemetry measurements on light point **CONFIG-9** controllers and cabinet controllers and properly reflected in the next data log sent to the CMS.

Change the reporting frequency for telemetry measurements

The Gateway can change the reporting frequency, i.e. how often it sends data logs to **CONFIG-10** the CMS, for telemetry measurements on light point controllers.

Update the firmware of the physical devices

The Gateway supports data package service and accepts a data package to update **CONFIG-11** firmware on a physical device such as a light point controller.

Monitoring

1 of 11

Report basic electrical values to the CMS

The Gateway measures mains voltage, current, active power, and power factor, and **MONITOR-1** sends these values to the CMS via the data logging service.

Report cumulative energy usage (kWh)

The Gateway sends the total energy used as a cumulative counter (kWh) to the CMS **MONITOR-2** via the data logging service.

Report lamp operating hours (runtime)

The Gateway reports each lamp's total hours of operation as a cumulative counter to the CMS via the data logging service. **MONITOR-3**

Report lamp switch-on count

The Gateway reports how many times each lamp has been switched on, as a cumulative counter to the CMS via the data logging service. **MONITOR-4**

Report power loss count

The Gateway reports the total number of power interruptions detected for each lamp as a cumulative counter to the CMS via the data logging service. **MONITOR-5**

Confirm dimming level after manual override command ✓

When a manual override is sent (e.g., set dimming level to X%), the Gateway forwards the command to the device and confirms, via on-demand request and data-logging service, that the actual dimming level matches (or closely follows) the requested level. **MONITOR-6**

Report temperature values

The Gateway sends temperature measurements from connected devices or sensors to the CMS via the data logging service. **MONITOR-8**

Report presence detection

The Gateway sends presence events or values from sensors to the CMS via the data logging service. **MONITOR-9**

Report ambient noise level

The Gateway sends noise level values to the CMS via the data logging service. **MONITOR-10**

Report dimming levels

The Gateway sends dimming level values to the CMS via the data logging service. **MONITOR-11**

Report firmware update status and progress

The Gateway reports firmware update events (start, progress, completion or failure) to the CMS. **MONITOR-12**

Controlling

1 of 7

Manually set a single light point

The Gateway accepts a manual override command from the CMS (e.g., set dimming level or switch ON/OFF) and applies it to one specific light point. **CONTROL-1**

Manually set the dimming level on a group of light points

The Gateway accepts a manual override command from the CMS and applies it to a defined group of light points. **CONTROL-2**

Manually set the dimming level on a single light point with a delay

The Gateway accepts a manual override command from the CMS that includes a delay (e.g., "in 10 minutes") and applies the change to one light point at the requested time. **CONTROL-3**

Manually change dimming level with a smooth ramp

The Gateway accepts a manual override command from the CMS that includes a ramp-up/ramp-down time and adjusts the dimming level on one light point smoothly to the requested level. **CONTROL-4**

Switch a light automatically using a photocell

The Gateway runs a local control program that turns a single light point ON and OFF based on the status of a local photocell. **CONTROL-5**

Adjust dimming level on presence detection

The Gateway runs a local control program that raises or lowers the dimming level of a single light point when a presence sensor is triggered. **CONTROL-6**

Adjust dimming level on noise detection

The Gateway runs a local control program that changes the dimming level of a single point when a noise sensor is triggered. **CONTROL-7**

Alarming

2 of 5

Detect and report lighting alarms ✓

The Gateway detects lighting-related issues (e.g., lamp/driver issues, high temperature) and send alarms to the CMS via the data-logging service. **ALARM-1**

Detect and report electrical alarms

The Gateway detects electrical issues (e.g., over/under-voltage, over-current, power loss) and sends alarms to the CMS via the data-logging service. **ALARM-2**

Report invalid schedules or control programs

If a calendar or control program is missing, invalid, or inconsistent, the Gateway raises an alarm and sends it to the CMS via the data-logging service. **ALARM-3**

Report sensor-activity events

When activity is detected by local sensors (e.g., presence or noise), the Gateway sends an event to the CMS via the data-logging service. **ALARM-4**

Provide alarm status on request

When the CMS asks for it, the Gateway returns the actual status of the alarms (e.g., active/inactive).

ALARM-5**Programming****6 of 9****Run a daily fixed time on/off and dimming schedule**

The Gateway receives a schedule that turns a light point ON/OFF and sets dimming level at specific times, the same every day of the year.

PROGRAM-1**Run an astro-clock on/off schedule with fixed-time dimming (daily)**

The Gateway switches a light point ON/OFF at sunrise/sunset with an adjustable time offset (\pm minutes) and applies a time-based dimming plan during the astro-clock active period, every night.

PROGRAM-2**Run a photocell-based on/off schedule with fixed-time dimming (daily)**

The Gateway turns a light point ON when the photocell indicates darkness and OFF when it is bright and follows a time-based dimming plan during the photocell's active period, every night.

PROGRAM-3**Combine photocell and astro-clock switching with fixed-time dimming (daily)**

The Gateway turns a light point ON/OFF based on whichever trigger happens first, photocell darkness/brightness or astro sunrise/sunset with offset and follows a time-based dimming plan during the active period, every night.

PROGRAM-4**Run an OFF period that crosses midnight (or midday)**

The Gateway turns lights OFF for a time window that crosses midnight (or midday). When the schedule resumes, the lights return to the last scheduled dimming level.

PROGRAM-5

Support special date ranges (seasonal exceptions) ✓

The Gateway handles calendars with a year-round default rule plus a higher-priority rule that applies between two dates (e.g., Sept 10-Oct 16). **PROGRAM-6**

Support weekly exceptions (e.g., weekends) ✓

The Gateway handles calendars with a year-round default rule plus a higher-priority rule that applies on specific weekdays (e.g., every Saturday and Sunday). **PROGRAM-7**

Support combined weekly and seasonal exceptions with priorities ✓

The Gateway handles layered calendars: a year-round default rule; a higher-priority weekend rule (e.g., every Sat/Sun); an even higher-priority rule for a special period (Day 1-Day 2); and, within that period, a highest-priority rule for specific days (e.g., Saturdays). The most specific rule takes precedence. **PROGRAM-8**

Run a sensor-based dynamic lighting control program

The Gateway executes a control program that changes dimming level based on sensor detection (e.g., presence). **PROGRAM-9**

Capability list

Security

Enabled ✓

Functions

Basic

The Basic function describes the properties related to the physical asset to which the logical device is associated, such as identification (assetId) and location information.

Attributes

#	Attribute	Description
✓	displayName	Display name of the asset.
✓	assetId	Customer identifier of the asset. If multiple devices have the same assetId it means they belong to the same asset.
✓	serial	Serial number of the device.
✓	hwType	Hardware type of the device.
✓	hwVersion	Hardware revision of the device.
✓	swType	Software type of device. This attribute may be useful if the same hardware supports multiple firmware versions with different functions.
✓	swVersion	Software version installed on the device.
✓	installationDate	The installation date of Physical Device.
✓	deviceReset	The physical device containing the logical device was reset.
✓	currentTime	Current time of the device defined as local time with time zone designator. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TimeFunction.currentTime instead.]
✓	commandConfirmation	Allows the CMS to reboot, factory reset or configuration reset of the device. Before rebooting or resetting the device this attribute has to be true. Default value = false
✓	reboot	Reboot the device. This operational attribute requires the commandConfirmation attribute value to be set to true.
✓	configurationReset	Reset the device configuration settings. This operational attribute requires the commandConfirmation attribute value to be set to true.

Events

#	Event type	Description
✓	deviceReset	The physical device containing the logical device was reset

Gateway

The Gateway function includes the necessary attributes to enable the communication between the CMS and the Gateway according to the TALQ Specification.

Attributes

#	Attribute	Description
✓	cmsUri	Base URI for TALQ communication that allows the Gateway to access the CMS. Must be an absolute URI. Other URI's for accessing CMS can be relative to this base.
✓	cmsAddress	CMS UUID address
✓	gatewayUri	Base URI for TALQ communication that allows the CMS to access the Gateway. Must be an absolute URI. Other URI's for accessing Gateway can be relative to this base.
✓	gatewayAddress	Gateway UUID address
✓	retryPeriod	Time duration before the Gateway retransmits a message for which expected response has not been received. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new GatewayFunction.gatewayRetryPeriod instead.]
✓	gatewayRetryPeriod	Time duration before the Gateway retransmits a message for which the expected response has not been received. This attribute can be used by the CMS to avoid requests overload. Although this attribute will be mandatory for Gateway in future MAJOR versions, to keep backward compatibility it is considered optional for the existing profiles.
✓	cmsRetryPeriod	Time duration before the CMS retransmits a message for which the expected response has not been received. This attribute can be used by the Gateway to avoid requests overload. Although this attribute will be mandatory for CMS in future MAJOR versions, to keep backward compatibility it is considered optional for the existing profiles.

- | | |
|--------------------------|---|
| ✓ gatewayNumberOfRetries | Maximum number of retries for a failed request sent by the Gateway for which expected response has not been received. Default value shall be 3. This attribute can be used by the CMS to avoid requests overload. Although this attribute will be mandatory for Gateway in future MAJOR versions, to keep backward compatibility it is considered optional for the existing profiles. |
| ✓ cmsNumberOfRetries | Maximum number of retries for a failed request sent by the CMS for which expected response has not been received. Default value shall be 3. This attribute can be used by the Gateway to avoid requests overload. Although this attribute will be mandatory for CMS in future MAJOR versions, to keep backward compatibility it is considered optional for the existing profiles. |
| ✓ crlUrn | URI where the Gateway can obtain the Certification Revocation List (CRL). |
| ✓ vendor | Vendor identification. |
| ✓ currentReleaseId | Release ID of currently deployed release. This is used in the data package service. |
| ✓ newCmsAttached | This attribute is updated if, prior to the current bootstrap, one or more other CMS were already attached. Support for more than one CMS is optional. |

Lamp Actuator

The Lamp Actuator function includes attributes related to lighting control and it represents the smallest unit for control purposes. In practice, however, a Lamp Actuator function can control combinations of several lamps and control gear but all in the same way, as if they are all one individual unit.

Attributes

#	Attribute	Description
✓	lampTypeId	TALQ Address of an existing lampType.
✓	defaultLightState	Sets the default light output for the lamp actuator. This shall be applicable if no other command is active. This attribute shall be set to 100% as default value.
✓	targetLightCommand	Latest command for the lamp actuator.

- ✓ **feedbackLightCommand** This attribute reflects the command in effect and it might deviate from the actualLightState due to propagation time or due to internal ODN specific mechanisms to handle the priority of the requests.
- ✓ **actualLightState** This attribute should reflect the physical state of the light source as much as possible, including factors such as CLO. It may be calculated or measured, depending on the specific ODN implementation, which is outside the scope of this specification.
- ✓ **calendarID** TALQ Address of the calendar controlling this lamp actuator. If this attribute is empty, the behavior shall be determined by the ODN. If the attribute is invalid, the ODN shall trigger a generic invalid address event and the behavior shall be determined by the ODN.
- ✓ **invalidCalendar** The lamp actuator function has been allocated a calendar that it cannot implement.
- ✓ **invalidProgram** The lamp actuator function has been allocated a control program that it cannot implement.
- ✓ **lightStateChange** Light state has changed.
- ✓ **invalidLampType** Indicates that the lamp type referred cannot be applied.
- ✓ **applicationType** Application Type of the lamp actuator depending on the use case. E.g.: Lamp actuator, Cabinet actuator

Events

#	Event type	Description
✓	lightStateChange	Light state has changed

Lamp Monitor

The Lamp Monitor function enables monitoring of lamp parameters. A Lamp Monitor function should be associated with a specific lamp/control gear combination. Multiple lamp monitor functions may be implemented by a single device.

Attributes

#	Attribute	Description
---	-----------	-------------

✓ lampTypeId	TALQ Address of an existing lamp type. If not set to a valid value, this shall be the lamp type used in the lamp actuator. If this attribute is not supported in the implementation, the lamp monitor shall use the lamp type specified in the corresponding lamp actuator.
✓ numberOfLamps	Number of lamps being monitored by the lamp monitor function.
✓ operatingHours	Number of hours the lamp is on. This is the value used in CLO and may be set by the CMS.
✓ supplyVoltage	RMS supply volts when supplyType is AC, supply voltage (V) when supplyType is DC.
✓ supplyCurrent	RMS supply current (A) when supplyType is AC, supply current (A) when supplyType is DC.
✓ activePower	Active power.
✓ reactivePower	Reactive power.
✓ apparentPower	Apparent Power.
✓ powerFactor	Active power/Apparent power.
✓ activeEnergy	Cumulative active energy (since installation or counter reset).
✓ lampPowerTooHigh	Lamp power is greater than expected lamp power + lampPowerTolerance.
✓ lampPowerTooLow	Lamp power is smaller than expected lamp power - lampPowerTolerance
✓ lampVoltageTooHigh	Level of lamp voltage (not supply voltage) is greater than highLampVoltageThreshold.
✓ lampVoltageTooLow	Level of lamp voltage (not supply voltage) is smaller than lowLampVoltageThreshold.
✓ lampFailure	The lamp is not operating as it is supposed to (e.g. the lamp is broken). This event shall be used to detect a situation where the lamp (or LED module(s)) should be lit, but produce no light. This could be detected by the current flowing or power consumed.
✓ currentTooHigh	Supply current is above the highCurrentThreshold defined in the lamp type.

✓ currentTooLow	Supply current is below the lowCurrentThreshold defined in the lamp type.
✓ supplyLoss	Indicates loss of mains power.
✓ invalidLampType	Indicates that the lamp type referred cannot be applied.
✓ supplyVoltageTooHigh	Level of supply voltage is above the highLampVoltageThreshold.
✓ supplyVoltageTooLow	Level of supply voltage is below the lowSupplyVoltageThreshold.
✓ highSupplyVoltageThreshold	Supply voltage above which the supplyVoltageTooHigh event is triggered.
✓ lowSupplyVoltageThreshold	Supply voltage below which the supplyVoltageTooLow event is triggered.
✓ applicationType	Application Type of the lamp monitor depending on the use case. E.g.: LED Monitor

Events

#	Event type	Description
✓	currentTooHigh	Supply current is above the highCurrentThreshold defined in the lamp type
✓	lampFailure	The lamp is not operating as it is supposed to (e.g. the lamp is broken). This event shall be used to detect a situation where the lamp (or LED module(s)) should be lit, but produce no light. This could be detected by the current flowing or power consumed.
✓	supplyVoltageTooHigh	Level of supply voltage is above the highLampVoltageThreshold.
✓	supplyVoltageTooLow	Level of supply voltage is below the lowSupplyVoltageThreshold.

Light Sensor

A Light Sensor function models the output of light sensor. This function is optional for both CMS and Gateway, but when supported the requirements in this section shall apply.

Attributes

#	Attribute	Description
✓	lightLevel	Illuminance level.

- ✓ applicationType Application Type of the light sensor depending on the use case.
E.g.: Day light detector

Events

#	Event type	Description
---	------------	-------------

Location Sensor*

The Location Sensor Function is used to indicate that an object has changed position attributes configurable by the CMS or based on internal setup of the vendor. For example, a specific location (latitude, longitude) of a device could be defined by the vendor. If the device is equipped with a GPS, it could send a specific event indicating that its position is different to the one defined by the CMS. We might also want to let the configuration to the vendor itself and simply define events notifying the CMS that the default configuration has changed. For example, a garbage bin could have its location defined based on a sensor placed on the floor. If the bin is not above this sensor, the vendor will trigger an event. In this last case, the CMS does not need to configure anything.

Attributes

#	Attribute	Description
✓	expectedLocation	Nominal location of the device
✓	locationChangedThreshold	Distance (meters)
✓	location	Location of the device
✓	locationChanged	Triggered when the difference between location and expectedLocation is above locationChangedThreshold
✓	applicationType	Application Type of the location sensor depending on the use case. E.g.: Pole Location

Events

#	Event type	Description
✓	locationChanged	Triggered when the difference between location and expectedLocation is above locationChangedThreshold

Time*

The Time function includes attributes related to generic control and it represents the smallest unit for control purposes.

Attributes

#	Attribute	Description
✓	timeZone	Time zone of the device. Time zone may be expressed in two formats. where is a time zone as defined in the zone.tab of the IANA timezone database [IANA]; and stdoffset[dst[offset][,start[/time],end[/time]]] as defined by the Open Group for posix systems [POSIX].
✓	currentTime	Current time of the device defined as local time with time zone designator.

Events

#	Event type	Description
---	------------	-------------

Luminaire Asset

This entity contains the managed and tracked attributes of a specific Luminaire, excluding the concept of Controller and Driver.

Attributes

#	Attribute	Description
✓	luminaireTypeAddress	Address of the Luminaire Type
✓	bracketTypeAddress	Address of the Bracket Type
✓	serial	Serial number of the Luminaire
✓	projectID	Name of the Project / Tender
✓	luminousFluxConfiguration	Programmed light output of the luminaire
✓	paintingColor	Painting color of the luminaire expressed as a color system-color value, (e.g: RAL-7035)
✓	virtualPowerOutput	Percentage of nominal power at which the light source should be set when the Command is set to 100%.
✓	installationTimestamp	Installation date and time of luminaire
✓	identification	Luminaire identification. (e.g: as per DiiA/D4i specification part 251 (MB1 extension)).
✓	identificationNumber	Luminaire identification number. (e.g: as per DiiA/D4i specification part 251 (MB1 extension))
✓	mountingOption	Installed direction of the luminaire to the support
✓	warrantyExpirationDate	Warranty expiration date. It can be reset
✓	manufactureYear	Year of manufacture of the luminaire.

✓ manufactureWeek	Week of manufacture of the luminaire.
✓ warrantyYears	Number of years for warranty of this individual luminaire. If a value is also present in the LuminaireType.warrantyYears, then this value could be considered as an override to that value. E.g., for extended or shortened warranty periods.
✓ applicationType	Application Type of the luminaire asset depending on the use case.

Controller Asset

This entity contains the managed and tracked attributes of a specific controller

Attributes

#	Attribute	Description
✓	controllerTypeAddress	Address of the Controller Type
✓	serial	Serial number of the Controller
✓	firmwareVersion	Version of the controller hardware firmware
✓	installationTimestamp	Installation date and time of OLC
✓	registrationTimestamp	Registration date and time of OLC
✓	projectID	Name of the Project / Tender
✓	controllerColor	Painting color of the controller expressed as a color system-color value, (e.g: RAL-7035)
✓	connectionType	Type of the connection to the luminaire
✓	warrantyExpirationDate	Warranty expiration date. It can be reset
✓	manufactureYear	Year of manufacture of the controller
✓	manufactureWeek	Week of manufacture of the controller
✓	applicationType	Application Type of the controller asset depending on the use case.

Services

Configuration Service

The TALQ Configuration Service enables discovery and configuration of devices and services

Options

#	Option	Value	Description
✓	commissioningSupported*		This ODN can support commissioning from the CMS side.
✓	devicesPaginationSupported*		This ODN can support pagination of devices.

Control Service

The Control service describes the mechanisms to operate the actuator functions in order to enable schedule based and override control

Options

#	Option	Value	Description
✓	supportedTypes	<ul style="list-style-type: none"> AbsoluteActivePeriod AstroClockActivePeriod AstroClockTimeControl* ccDate* ccDay* 	Control Program and calendar options supported are defined by announcing support for the given modes
✓	maximumCalendars		Maximum number of calendars supported
✓	maximumPrograms		Maximum number of control programs supported
✓	maxProgramsPerCalendar		Maximum number of control programs per calendar
✓	maxSwitchPointsPerProgram		Maximum number of switching points per control program

- ✓ maxActivePeriodsPerProgram Maximum number of active periods per control program
- ✓ programSecondsSupported* Indicates whether the field of seconds is supported in programs.

Events

#	Event Type	Description
✓	invalidCalendar	An invalid calendar has been provided by the CMS to the ODN
✓	invalidProgram	A control program has been provided by the CMS, which cannot be implemented by the ODN

Data Collection Service

The TALQ Data Collection Service is a provision to configure how ODN measurements, status information and events are logged, and when or under what conditions the logged data is transferred to the CMS

Options

#	Option	Value	Description
✓	supportedModes	<ul style="list-style-type: none"> • EventRecordingMode • VendorRecordingMode • ImmediateReportingMode 	Recording and Reporting modes supported

Events

#	Event Type	Description
✓	invalidLoggerConfig	The CMS has provided a data logger configuration that cannot be implemented by the ODN

On Demand Data Request Service

This service provides the mechanism to access attributes in the logical devices by requesting attribute values from the ODN

Asset Management Service

The TALQ Asset Management Service provides a mechanism to transfer the types needed by the asset management functions

Objects

Luminaire Type

The LuminaireType consists of a set of attributes that together characterize, i.e.: are generic for, a given luminaire, excluding the concept of Controller, Driver and Bracket.

Properties

#	Property	Description
✓	address	TALQ address of the Luminaire Type
✓	name	Descriptive name of the LuminaireType
✓	gtin	Global Trade Item Number of luminaire
✓	manufacturerName	Name of manufacturer
✓	productFamily	Product family name of luminaire
✓	model	Product model of luminaire
✓	maximumLuminousFluxOutput	Maximum Light Output luminous flux output
✓	minimumLuminousFluxOutput	Minimum Light Output of the luminaire
✓	lightSourceType	Light source type.
✓	lightDistributionType	Enumeration of possible light distribution type, using the Zhaga D4i enumeration. Please refer to ZD4i standard for more details.
✓	maximumPower	Maximum power that the Luminaire can operate at
✓	powerAtMinimumDimLevel	Power at minimum dim level for the luminaire.
✓	materialEnclosure	Material of enclosure of the body of the luminaire
✓	materialLightCover	Material of light cover [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new materialLightCover instead.]

✓ materialLightCover	Material of light cover
✓ luminaireEfficacy	Efficacy of the luminaire
✓ warmUpTime	Sets the delay after a Switch ON command during which the lamp actuator shall not perform any dimming command.
✓ maxOperatingHours	Maximum number of operating hours that the lamp is supposed to live with a given specification. This attribute can be used to set the old lamp attributes when the lamp reaches its expected useful life.
✓ lumenDepreciationCurve	Ordered set of entries (cumulative operating hours, correction factor in %) that form a piece wise linear approximation of the lumen depreciation correction factor curve. The first cumulative hours should be 0 and the last correction factor should be 100%. E.g.: 0 h, 80%; 5000 h, 85%; 10000 h, 90%; 15000 h, 95%; 20000 h, 100%.
✓ cloType	Determines where CLO (Constant Lumen Output) is implemented in the lamp control gear or in the ODN (e.g. control device). This CLO profile is needed even when CLO is implemented by the driver in order to obtain the expected lamp power.
✓ lightSourceManufacturerName	Name of light source manufacturer
✓ lightSourceLedEfficacy	Efficacy of the LED
✓ lor	Light Output Ratio (total light output of the lighting fixture divided by the luminaire flux of the light source) (e.g: 70.5%)
✓ cct	Color temperature of the luminaire (Correlated Color Temperature)
✓ cri	Color rendering index (0 to 100) of the luminaire
✓ backlightCutType	Backwards light blocking solution (e.g: by optics; or reflector; or louvre)

Bracket Type

The BracketType consists of a set of attributes that together characterize, i.e: are generic for, a given Bracket.

Properties

#	Property	Description
✓	address	TALQ address of the Bracket Type
✓	name	Descriptive name of the Bracket Type
✓	manufacturerName	Name of manufacturer
✓	productFamily	Product family name of bracket
✓	model	Product model of bracket

Controller Type

The ControllerType consists of a set of attributes that together characterize, i.e. are generic for, a given Controller.

Properties

#	Property	Description
✓	address	TALQ address of the Controller Type
✓	name	Descriptive name of the Controller Type
✓	locationPrecision	Accuracy of the location determination
✓	manufacturerName	Name of manufacturer
✓	productFamily	Product family name of the controller
✓	model	Model of the Controller
✓	mechanicalInterfaces	Type of mechanical connection or socket
✓	electricalInterfaces	The control interface protocol type of the connector of the driver.
✓	protocols	Type of digital communication of the controller

Event log data

Event log data contains a single event, with eventType and value, in each single log entry. It also includes information about whether the log denotes the start or end of the event. Furthermore additional information can be added with the info attribute.

Properties

#	Property	Description
✓	eventType	Identifier of event reported

- ✓ **srcAddress** Address of Logical device or function within a logical device which is the source of the event or to which this event applies

Command


A command defines a type of control action that can be applied to a function. Commands can be generated by a manual override action or by a control program.

Properties

#	Property	Description
✓	state	Light state to be applied to the lamp actuator
✓	cmsRefId	CMS reference, which can be used for data logging. The cmsRefId in a Command is a free text to be used by the CMS for any purpose, e.g: to differentiate contexts. It is a token that allows the CMS to match client requests to the original notification.

: The Certification Test Tool is designed to provide a high level of confidence that complementary systems can communicate successfully. As both the protocol and the test tool evolve, all mandatory and other core tests are confirmed by comparison with real-life scenarios (plug-fest or similar). Some tests of optional and more peripheral features may not yet have been confirmed in this way; such features are identified with an asterisk ().

This Capability List is based on a certification session performed by the TALQ Certification Tool (v2.7.0-online.1) on 2026-02-27 19:56:47.040 +0800.

 and **TALQ** are trademarks owned by the TALQ Consortium.

© TALQ Consortium

