

# **Certified Capability List**

This Capability List is based on a certification session performed by the TALQ Certification Tool (v2.5.1update.2) on 2024-03-11 09:03:41.233 +0800.

The Capability List is a consolidated list of TALQ features which are implemented in a product.

The tool has succesfully performed 28 tests.

## **Product details**

Droduct	Nama	StarRiver Pro
FIOUUGE	Name	SIMILIVELE IO

Company Shanghai Sansi Electronic Engineering Co., Ltd.

Type CMS

https://192.168.230.128:3001

**Notes** 

Generated on 2024-03-11 09:03:41.233 +0800

Supported profiles Lighting

API version certified: 2.5.1

Certification performed by app version: 2.5.1-update.2

# Capability list

## **Security**

about:blank 1/12 Enabled 🗸

## **Functions**

### **Basic**

The Basic function describes the properties related to the physical asset to which the logical device is associated, such as identification (assetId) and location information.

### **Attributes**

# Attribute	Description
✓ assetId	Customer identifier of the asset. If multiple devices have the same assetId it means they belong to the same asset.
✓ serial	Serial number of the device.
✓ hwType	Hardware type of the device.
✓ swVersion	Software version installed on the device.
✓ location	Latitude, Longitude and Altitude. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new LocationSensorFunction.location instead.]
✓ timeZone	Time zone of the device. Time zone may be expressed in two formats. <timezone> where <timezone> is a time zone as defined in the zone.tab of the IANA timezone database [IANA]; and stdoffset[dst[offset][,start[/time],en d[/time]]] as defined by the Open Group for posix systems [POSIX]. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TimeFunction.timeZone instead.]</timezone></timezone>
✓ currentTime	Current time of the device defined as local time with time zone designator. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TimeFunction.currentTime instead.]

## **Events**

# Event type	Description
✓ deviceReset	The physical device containing the logical device was reset
✓ batteryMode	Device operating in battery mode
✓ installationMod	de Device is being installed

about:blank 2/12

✓ maintenanceMode	Device is undergoing maintenance
✓ cabinetDoorOpen	Cabinet door is open. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new SegmentMonitor.cabinetDoorOpen instead.]
✓ batteryShutdown	Indicates the device has shut down due to battery discharge
✓ locationUpdated	Indicates the location of a device has changed.

### Communication

The Communication Function contains attributes related to the communication within the ODN, and between ODN devices and Gateways. Although communication within the ODN is outside the scope of the TALQ Smart City Protocol, this Function enables access to a minimum set of configuration and state information of the ODN communication interface in order to facilitate system management from the CMS.

### **Attributes**

#	Attribute	Description
~	physicalAddress	Physical address of the device. For example, IEEE MAC address. This attribute can be used to map between logical and physical devices. The format is specific to the ODN implementation.
<b>~</b>	parentAddress	TALQ Address of the parent device, e.g. gateway. It shall point to a specific communication function.

### **Events**

#	Event type	Description
<b>~</b>	communicationFailure	This event is generated by the ODN when the communication function is not operating as expected

### Gateway

The Gateway function includes the necessary attributes to enable the communication between the CMS and the Gateway according to the TALQ Specification.

### **Attributes**

|--|

about:blank 3/12

~	cmsUri	Base URI for TALQ communication that allows the Gateway to access the CMS. Must be an absolute URI. Other URI's for accessing CMS can be relative to this base.
<b>~</b>	cmsAddress	CMS UUID address
<b>✓</b>	gatewayUri	Base URI for TALQ communication that allows the CMS to access the Gateway. Must be an absolute URI. Other URI's for accessing Gateway can be relative to this base.
<b>~</b>	gatewayAddress	Gateway UUID address
<b>~</b>	crlUrn	URI where the Gateway can obtain the Certification Revocation List (CRL).
<b>~</b>	vendor	Vendor identification.

### **Lamp Actuator**

The Lamp Actuator function includes attributes related to lighting control and it represents the smallest unit for control purposes. In practice, however, a Lamp Actuator function can control combinations of several lamps and control gear but all in the same way, as if they are all one individual unit.

### **Attributes**

# Attribute	Description
✓ defaultLightState	Sets the default light output for the lamp actuator. This shall be applicable if no other command is active. This attribute shall be set to 100% as default value.
<ul><li>targetLightCommand</li></ul>	Latest command for the lamp actuator.
✓ feedbackLightCommand	This attribute reflects the command in effect and it might deviate from the actualLightState due to propagation time or due to internal ODN specific mechanisms to handle the priority of the requests.
✓ actualLightState	This attribute should reflect the physical state of the light source as much as possible, including factors such as CLO. It may be calculated or measured, depending on the specific ODN implementation, which is outside the scope of this specification.
✓ calendarID	TALQ Address of the calendar controlling this lamp actuator. If this attribute is empty, the behavior shall be determined by the ODN. If the attribute is invalid, the ODN shall trigger a generic invalid address event and the behavior shall be determined by the ODN.

### **Events**

about:blank 4/12

#	Event type	Description
<b>~</b>	lightStateChange	Light state has changed
<b>~</b>	invalidCalendar	The lamp actuator function has been allocated a calendar that it cannot implement
<b>~</b>	invalidProgram	The lamp actuator function has been allocated a control program that it cannot implement

## **Lamp Monitor**

The Lamp Monitor function enables monitoring of lamp parameters. A Lamp Monitor function should be associated with a specific lamp/control gear combination. Multiple lamp monitor functions may be implemented by a single device.

### **Attributes**

# Attribute	Description
✓ numberOfLamps	Number of lamps being monitored by the lamp monitor function.
✓ operatingHours	Number of hours the lamp is on. This is the value used in CLO and may be set by the CMS.
✓ temperature	Temperature of the device implementing this function.  [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TemperatureSensorFunction.temperature instead.]
✓ supplyVoltage	RMS supply volts when supplyType is AC, supply voltage (V) when supplyType is DC.
✓ supplyCurrent	RMS supply current (A) when supplyType is AC, supply current (A) when supplyType is DC.
✓ activePower	Active power.
✓ powerFactor	Active power/Apparent power.
✓ powerFactorSense	Phase sense of power factor.
✓ activeEnergy	Cumulative active energy (since installation or counter reset).

## **Events**

# Event type	Description
✓ lampPowerTooHigh	Lamp power is greater than expected lamp power + lampPowerTolerance
✓ lampPowerTooLow	Lamp power is smaller than expected lamp power - lampPowerTolerance

about:blank 5/12

✓ lampVoltageTooHigh	Level of lamp voltage (not supply voltage) is greater than highLampVoltageThreshold.
✓ lampVoltageTooLow	Level of lamp voltage (not supply voltage) is smaller than lowLampVoltageThreshold.
✓ currentTooHigh	Supply current is above the highCurrentThreshold defined in the lamp type
✓ currentTooLow	Supply current is below the lowCurrentThreshold defined in the lamp type
✓ powerFactorTooLow	The power factor is below powerFactorThreshold
✓ lampFailure	The lamp is not operating as it is supposed to (e.g. the lamp is broken). This event shall be used to detect a situation where the lamp (or LED module(s)) should be lit, but produce no light. This could be detected by the current flowing or power consumed.
✓ highTemperature	Indicates temperature is above the high threshold
✓ relayFailure	Set in case of internal relay is failing
✓ absoluteLampPowerTooHigh	Indicates the power is above the lampPowerHighThreshold in the lamp type
✓ absoluteLampPowerTooLow	Indicates the power is below the lampPowerLowThreshold in the lamp type
✓ controlGearCommFailure	Indicates failure of the control gear
✓ cyclingFailure	Indicates the lamp is constantly switching ON and OFF in an unexpected manner
✓ supplyLoss	Indicates loss of mains power
✓ contactorError	Indicates error in contactor
✓ lampUnexpectedOn	Indicates lamp is unexpectedly on
✓ leakageDetected	Indicates that an earth leakage fault has been detected

### **Electrical Meter**

The electrical meter function supports electrical metering capabilities including measurements of voltage, current, power, energy, and power factor. This function may be associated with Luminaire Controllers, Cabinet Controllers or electrical meters installed in switch boxes. ODNs may implement both single phase and three phase meters. Typically meters within a control device will be single phase and stand-alone meters. A street side cabinet may have single phase or three phase meters.

## **Attributes**

about:blank 6/12

#	Attribute	Description
<b>~</b>	totalPower	Sum of the active power consumed on phase 1, 2 and 3, or just the power for a single phase meter.
<b>~</b>	totalActiveEnergy	Total cumulative kWh measured by the meter since installation date (or counter reset).
<b>~</b>	totalPowerFactor	Total active power divided by total apparent power.
<b>~</b>	supplyVoltage	Average between Phase1 RMS Voltage, Phase2 RMS Voltage and Phase3 RMS Voltage, or in the case of a single phase meter just the RMS supply voltage.
<b>~</b>	totalCurrent	Sum of the RMS currents on phase 1, 2 and 3.
<b>~</b>	averageCurrent	Average RMS current on phase 1, 2 and 3.
Ξve	ents	
#	Event type	Description

### **Photocell**

A Photocell function models the capabilities of a photocell that can be used for lighting control. This function shall be supported by the CMS and optionally by the ODNs (Gateway).

### **Attributes**

#	Attribute	Description
<b>~</b>	onLevel	Illuminance level at which the photocell switches to on state.
<b>~</b>	offLevel	Illuminance level at which the photocell switches to off state.
<b>~</b>	photocellOutput	Output state of the photocell. Possible values are ON (means the illuminance level has fallen below the onLevel) and OFF (means the illuminance level has risen above the offLevel).

## **Events**

#	Event type	Description
<b>~</b>	photocellOutputOn	The photocell output has changed to ON

## **Services**

about:blank 7/12

### **Configuration Service**

The TALQ Configuration Service enables discovery and configuration of devices and services

## **Options**

# Option Value Description

#### **Control Service**

The Control service describes the mechanisms to operate the actuator functions in order to enable schedule based and override control

## **Options**

#	Option	Value	Description
•••	<b>O P U O O O O O O O O O O</b>	Tu.uo	<b>2</b> 000pt.o

### **Events**

# Event type Description	#	<b>Event Type</b>	Description
--------------------------	---	-------------------	-------------

- ✓ invalidCalendar An invalid calendar has been provided by the CMS to the ODN
- ✓ invalidProgram A control program has been provided by the CMS, which cannot be implemented by the ODN

#### **Data Collection Service**

The TALQ Data Collection Service is a provision to configure how ODN measurements, status information and events are logged, and when or under what conditions the logged data is transferred to the CMS

## **Options**

#	Option	Value	Description
<b>~</b>	supportedModes	<ul><li>VendorRecordingMode</li><li>EventRecordingMode</li><li>ImmediateReportingMode</li></ul>	Recording and Reporting modes supported

### **Events**

#	Event Type	Description
<b>~</b>	invalidLoggerConfig	The CMS has provided a data logger configuration that cannot be implemented by the ODN

about:blank 8/12

### On Demand Data Request Service

This service provides the mechanism to access attributes in the logical devices by requesting attribute values from the ODN

## **Group Management Service**

This service provides the mechanisms to define and manage groups

## **Options**

#	Option	Value	Description

#### **Test Service**

This service provides a mechanism to reduce the human intervention during the certification tests, enabling the certification tests to maximise automation

## **Objects**

### Event log data

Event log data contains a single event, with eventType and value, in each single log entry. It also includes information about whether the log denotes the start or end of the event. Furthermore additional information can be added with the info attribute.

### **Properties**

# Property	Description
✓ eventType	Identifier of event reported
✓ srcAddress	Address of Logical device or function within a logical device which is the source of the event or to which this event applies
✓ startEndFlag	If the event denotes either the start or end of a 'special' period, this flag shall be included

#### Command

about:blank 9/12

A command defines a type of control action that can be applied to a function. Commands can be generated by a manual override action or by a control program.

## **Properties**

# P	Property	Description
<b>✓</b> S	tate	Light state to be applied to the lamp actuator
✓ re	eason	Indicates the command was triggered by override, sensor or control program
<b>✓</b> c	cmsRefld	CMS reference, which can be used for data logging. The cmsRefld in a Command is a free text to be used by the CMS for any purpose, e.g: to differentiate contexts. It is a token that allows the CMS to match client requests to the original notification.
✓ re	efAddress	Reference to the source of the command, e.g. sensor or control program
<b>✓</b> s	etart	Time when the control action resulting from command shall start. This attribute is used only with override commands to set a time to start an override action. If not specified, the override command starts immediately.
<b>✓</b> e	expiration	Time when the control action resulting from command shall be terminated. This attribute is used only with override commands to set a time to stop an override action. After the expiration of an override command, the system should go back to the state defined by the active control program. If not specified, there is no expiration for the override command.
<b>✓</b> ra	ampToLevelTime*	The time (in seconds) taken for the value to ramp to the specified level. The change will be finished rampToLevelTime seconds after: the scheduled time if the change comes from a control program; the reception of the request, or the command.start time attribute, if the change comes from an override command, or; the sensor event is raised if the control is sensor-based. If actions related to one command remain to be completed when a subsequent command is received, the subsequent command shall take precedence.

about:blank 10/12

rampFromLevelTime\*
The time (in seconds) taken for the value to ramp to the specified level. The change will be finished rampFromLevelTime seconds after: the scheduled time if the change comes from a control program; the reception of the request if the change comes from an override command; expiry of the related command, or; the sensor event is lowered and the hold time subsequently expires if the control is sensor-based. If actions related to one command remain to be completed when a subsequent command is received, the subsequent command shall take precedence.

#### Group

A group is set of entities that can be addressed by the same group address. Devices and functions within devices can be assigned to a group. A group may also include other groups as members.

## **Properties**

#	Property	Description
<b>~</b>	address	Group address
<b>~</b>	members	TALQ Addresses of members of the group

★: The Certification Test Tool is designed to provide a high level of confidence that complementary systems can communicate successfully. As both the protocol and the test tool evolve, all mandatory and other core tests are confirmed by comparison with real-life scenarios (plug-fest or similar). Some tests of optional and more peripheral features may not yet have been confirmed in this way; such features are identified with an asterisk (\*).

## **Functional tests**

The Functional Tests help the customers to understand what a TALQ-certified product is capable of. Each Functional Test is related to a set of required TALQ technical test cases.

about:blank

This Capability List is based on a certification session performed by the TALQ Certification Tool (v2.5.1-update.2) on 2024-03-11 09:03:41.233 +0800.

and **TALQ** are trademarks owned by the TALQ Consortium.

**G** TALQ Consortium



about:blank