



Certified Capability List

This Capability List is based on a certification session performed by the *TALQ Certification Tool (v2.5.0-update.1)* on *2023-01-26 14:06:32.014 +0100*.

The Capability List is a consolidated list of TALQ features which are implemented in a product.

The tool has succesfully performed *113 tests*.

Product details

| | |
|------------------------|--|
| Product Name | Citylinx |
| Company | BeeZeeLinx |
| Type | CMS |
| URL | https://renan-lx3.citylinx.io/reports/api/talq_tct |
| Notes | |
| Generated on | 2023-01-26 14:06:32.014 +0100 |
| Supported profiles | <ul style="list-style-type: none">• Environmental Monitoring• Lighting• Lighting Asset Management• Smart Parking• Smart Traffic• Waste Management |
| API version certified: | 2.5.0 |

Certification performed by app version: 2.5.0-update.1

Capability list

Security

Enabled ✓

Functions

Basic

The Basic function describes the properties related to the physical asset to which the logical device is associated, such as identification (assetId) and location information.

Attributes

| # | Attribute | Description |
|---|------------------|--|
| ✓ | displayName | Display name of the asset. |
| ✓ | assetId | Customer identifier of the asset. If multiple devices have the same assetId it means they belong to the same asset. |
| ✓ | serial | Serial number of the device. |
| ✓ | hwType | Hardware type of the device. |
| ✓ | hwVersion | Hardware revision of the device. |
| ✓ | swType | Software type of device. This attribute may be useful if the same hardware supports multiple firmware versions with different functions. |
| ✓ | swVersion | Software version installed on the device. |
| ✓ | installationDate | The installation date of Physical Device. |
| ✓ | location | Latitude, Longitude and Altitude. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new LocationSensorFunction.location instead.] |
| ✓ | deviceReset | The physical device containing the logical device was reset. |
| ✓ | softwareUpdating | Indicates software updating is in progress. |
| ✓ | hardwareUpdating | Indicates that hardware associated with this logical device has been updated. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new hardwareUpdated instead.] |
| ✓ | hardwareUpdated | Indicates that hardware associated with this logical device has been updated. |
| ✓ | batteryMode | Device operating in battery mode. |
| ✓ | installationMode | Device is being installed. |

| | |
|-----------------------|---|
| ✓ maintenanceMode | Device is undergoing maintenance, where maintenance may include hardware or software related maintenance actions. |
| ✓ cabinetDoorOpen | Cabinet door is open. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new SegmentMonitor.cabinetDoorOpen instead.] |
| ✓ batteryShutdown | Indicates the device has shut down due to battery discharge. |
| ✓ locationUpdated | Indicates the location of a device has changed, but detecting the change is outside the scope of the TALQ Specification. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new LocationSensorFunction.locationChanged instead.] |
| ✓ timeZone | Time zone of the device. Time zone may be expressed in two formats. <timezone> where <timezone> is a time zone as defined in the zone.tab of the IANA timezone database [IANA]; and stdoffset[dst[offset][,start[/time],end[/time]]] as defined by the Open Group for posix systems [POSIX]. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TimeFunction.timeZone instead.] |
| ✓ ntpServers | List of NTP servers to use for time synchronization (Hostname or IP address). [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TimeFunction.ntpServers instead.] |
| ✓ ntpSynchPeriod | Number of hours between two time synchronization updates. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TimeFunction.ntpSynchPeriod instead.] |
| ✓ currentTime | Current time of the device defined as local time with time zone designator. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TimeFunction.currentTime instead.] |
| ✓ commandConfirmation | Allows the CMS to reboot, factory reset or configuration reset of the device. Before rebooting or resetting the device this attribute has to be true. Default value = false |
| ✓ reboot | Reboot the device. This operational attribute requires the commandConfirmation attribute value to be set to true. |
| ✓ factoryReset | Reset the device to factory settings. This operational attribute requires the commandConfirmation attribute value to be set to true. |
| ✓ configurationReset | Reset the device configuration settings. This operational attribute requires the commandConfirmation attribute value to be set to true. |
| ✓ operatingHours | Number of operating hours of the device. |

Events

| # | Event type | Description |
|---|------------|-------------|
|---|------------|-------------|

| | |
|--------------------|---|
| ✓ deviceReset | The physical device containing the logical device was reset |
| ✓ softwareUpdating | Indicates software updating is in progress |
| ✓ hardwareUpdated | Indicates that hardware associated with this logical device has been updated |
| ✓ batteryMode | Device operating in battery mode |
| ✓ installationMode | Device is being installed |
| ✓ maintenanceMode | Device is undergoing maintenance |
| ✓ cabinetDoorOpen | Cabinet door is open. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new SegmentMonitor.cabinetDoorOpen instead.] |
| ✓ batteryShutdown | Indicates the device has shut down due to battery discharge |
| ✓ locationUpdated | Indicates the location of a device has changed. |

Communication

The Communication Function contains attributes related to the communication within the ODN, and between ODN devices and Gateways. Although communication within the ODN is outside the scope of the TALQ Smart City Protocol, this Function enables access to a minimum set of configuration and state information of the ODN communication interface in order to facilitate system management from the CMS.

Attributes

| # | Attribute | Description |
|---|----------------------|--|
| ✓ | communicationType | Type of communication technology implemented by the ODN (e.g. power line, wireless). |
| ✓ | logicalAddress | Logical address for communication within the ODN scope (IP address, Short Address, ...). |
| ✓ | altLogicalAddress | Additional logical address used for communication within the ODN, for instance, group communication address (not a TALQ group address). |
| ✓ | physicalAddress | Physical address of the device. For example, IEEE MAC address. This attribute can be used to map between logical and physical devices. The format is specific to the ODN implementation. |
| ✓ | parentAddress | TALQ Address of the parent device, e.g. gateway. It shall point to a specific communication function. |
| ✓ | timeToLive | Number of times a packet can be forwarded within the ODN. |
| ✓ | repeatingEnabled | Describes whether repeating functionality is enabled at the device. |
| ✓ | transmitPower | Transmit power used by the device within the ODN. |
| ✓ | numberOfHops | Number of hops between the gateway and the ODN device represented by the device including this function. |
| ✓ | communicationQuality | Indicator of the quality of the communication with the device. 100% means good quality. |

| | |
|------------------------|--|
| ✓ communicationFailure | This attribute is updated by the ODN when the communication function is not operating as expected. |
| ✓ applicationType | Application Type of the communication function depending on the use case. E.g.: PL Communication Monitor |

Events

| # | Event type | Description |
|---|----------------------|---|
| ✓ | communicationFailure | This event is generated by the ODN when the communication function is not operating as expected |

Gateway

The Gateway function includes the necessary attributes to enable the communication between the CMS and the Gateway according to the TALQ Specification.

Attributes

| # | Attribute | Description |
|---|--------------------|---|
| ✓ | cmsUri | Base URI for TALQ communication that allows the Gateway to access the CMS. Must be an absolute URI. Other URI's for accessing CMS can be relative to this base. |
| ✓ | cmsAddress | CMS UUID address |
| ✓ | gatewayUri | Base URI for TALQ communication that allows the CMS to access the Gateway. Must be an absolute URI. Other URI's for accessing Gateway can be relative to this base. |
| ✓ | gatewayAddress | Gateway UUID address |
| ✓ | retryPeriod | Time duration before the Gateway retransmits a message for which expected response has not been received. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new GatewayFunction.gatewayRetryPeriod instead.] |
| ✓ | gatewayRetryPeriod | Time duration before the Gateway retransmits a message for which the expected response has not been received. This attribute can be used by the CMS to avoid requests overload. Although this attribute will be mandatory for Gateway in future MAJOR versions, to keep backward compatibility it is considered optional for the existing profiles. |
| ✓ | cmsRetryPeriod | Time duration before the CMS retransmits a message for which the expected response has not been received. This attribute can be used by the Gateway to avoid requests overload. Although this attribute will be mandatory for CMS in future MAJOR versions, to keep backward compatibility it is considered optional for the existing profiles. |

| | |
|--------------------------|---|
| ✓ gatewayNumberOfRetries | Maximum number of retries for a failed request sent by the Gateway for which expected response has not been received. Default value shall be 3. This attribute can be used by the CMS to avoid requests overload. Although this attribute will be mandatory for Gateway in future MAJOR versions, to keep backward compatibility it is considered optional for the existing profiles. |
| ✓ cmsNumberOfRetries | Maximum number of retries for a failed request sent by the CMS for which expected response has not been received. Default value shall be 3. This attribute can be used by the Gateway to avoid requests overload. Although this attribute will be mandatory for CMS in future MAJOR versions, to keep backward compatibility it is considered optional for the existing profiles. |
| ✓ crlUrn | URI where the Gateway can obtain the Certification Revocation List (CRL). |
| ✓ vendor | Vendor identification. |
| ✓ pkgUrl | URL pointing at location packages can be downloaded. This is used in the data package service. |
| ✓ currentReleaseId | Release ID of currently deployed release. This is used in the data package service. |
| ✓ newCmsAttached | This attribute is updated if, prior to the current bootstrap, one or more other CMS were already attached. Support for more than one CMS is optional. |

Lamp Actuator

The Lamp Actuator function includes attributes related to lighting control and it represents the smallest unit for control purposes. In practice, however, a Lamp Actuator function can control combinations of several lamps and control gear but all in the same way, as if they are all one individual unit.

Attributes

| # | Attribute | Description |
|---|-------------|--|
| ✓ | lampTypeId | TALQ Address of an existing lampType. |
| ✓ | outputPort | Identifier of the output port that is controlled by the lamp actuator. |
| ✓ | standbyMode | Defines the behavior of the lamp actuator when output level is set to zero. If OFF, light output level is zero with no power to the lamp control gear. If ON, light output level is zero but power is delivered to the lamp control gear (standby mode). |
| ✓ | cloEnabled | Determines whether a Constant Light Output (CLO) correction factor is used. CLO is used to compensate for lumen output degradation over the life time of the lamp. If CLO is enabled, lamps are dimmed part of the lampType. |

| | |
|----------------------------|---|
| ✓ defaultLightState | Sets the default light output for the lamp actuator. This shall be applicable if no other command is active. This attribute shall be set to 100% as default value. |
| ✓ targetLightCommand | Latest command for the lamp actuator. |
| ✓ feedbackLightCommand | This attribute reflects the command in effect and it might deviate from the actualLightState due to propagation time or due to internal ODN specific mechanisms to handle the priority of the requests. |
| ✓ actualLightState | This attribute should reflect the physical state of the light source as much as possible, including factors such as CLO. It may be calculated or measured, depending on the specific ODN implementation, which is outside the scope of this specification. |
| ✓ maintenanceFactorEnabled | Indicates whether maintenance compensation is enabled. A maintenance factor can be added in addition to the CLO correction factor to account effects of maintenance (e.g. cleaning) of the luminaire on the lumen output. |
| ✓ maintenancePeriod | Period (Hours) after which maintenance factor is 100%. The assumption is that the maintenance correction factor vs. time curve is linear. |
| ✓ maintenanceFactor | Initial correction factor applied when the luminaire is cleaned. |
| ✓ lastMaintenanceDate | Date when the luminaire was last cleaned (used to reset the maintenance factor). |
| ✓ calendarID | TALQ Address of the calendar controlling this lamp actuator. If this attribute is empty, the behavior shall be determined by the ODN. If the attribute is invalid, the ODN shall trigger a generic invalid address event and the behavior shall be determined by the ODN. |
| ✓ invalidCalendar | The lamp actuator function has been allocated a calendar that it cannot implement. |
| ✓ invalidProgram | The lamp actuator function has been allocated a control program that it cannot implement. |
| ✓ lightStateChange | Light state has changed. |
| ✓ targetLightCommandChange | The targetLightCommand operational attribute has changed. |
| ✓ programChange | The control program applicable to the lamp actuator has changed (these are the points at which the calendar changes the program). |
| ✓ calendarChange | The calendar applicable to the lamp actuator has changed. |
| ✓ invalidLampType | Indicates that the lamp type referred cannot be applied. |
| ✓ applicationType | Application Type of the lamp actuator depending on the use case. E.g.: Lamp actuator, Cabinet actuator |

Events

| # | Event type | Description |
|---|--------------------------|--|
| ✓ | lightStateChange | Light state has changed |
| ✓ | invalidCalendar | The lamp actuator function has been allocated a calendar that it cannot implement |
| ✓ | invalidProgram | The lamp actuator function has been allocated a control program that it cannot implement |
| ✓ | targetLightCommandChange | The targetLightCommand operational attribute has changed |
| ✓ | programChange | The control program applicable to the lamp actuator has changed |
| ✓ | calendarChange | The calendar applicable to the lamp actuator has changed |
| ✓ | invalidLampType | Indicates that the lamp type referred cannot be applied. |

Lamp Monitor

The Lamp Monitor function enables monitoring of lamp parameters. A Lamp Monitor function should be associated with a specific lamp/control gear combination. Multiple lamp monitor functions may be implemented by a single device.

Attributes

| # | Attribute | Description |
|---|---------------------|---|
| ✓ | supplyType | Supply type of the lamp. Accepted values are: AC, DC. |
| ✓ | monitoringReference | Name of the entity (or physical device) being monitored by this function. |
| ✓ | numberOfLamps | Number of lamps being monitored by the lamp monitor function. |
| ✓ | switchOnCounter | Cumulative number of ON/OFF cycles since installation of the lamp. The wrap around value is $2e32 - 1$. |
| ✓ | operatingHours | Number of hours the lamp is on. This is the value used in CLO and may be set by the CMS. |
| ✓ | temperature | Temperature of the device implementing this function. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TemperatureSensorFunction.temperature instead.] |
| ✓ | supplyVoltage | RMS supply volts when supplyType is AC, supply voltage (V) when supplyType is DC. |
| ✓ | supplyCurrent | RMS supply current (A) when supplyType is AC, supply current (A) when supplyType is DC. |
| ✓ | activePower | Active power. |
| ✓ | reactivePower | Reactive power. |

| | |
|----------------------|--|
| ✓ apparentPower | Apparent Power. |
| ✓ powerFactor | Active power/Apparent power. |
| ✓ powerFactorSense | Phase sense of power factor. |
| ✓ activeEnergy | Cumulative active energy (since installation or counter reset). |
| ✓ supplyLossCount | Incrementing count of supply losses. The wrap around value is $2e32 - 1$. |
| ✓ lampPowerTooHigh | Lamp power is greater than expected lamp power + lampPowerTolerance. |
| ✓ lampPowerTooLow | Lamp power is smaller than expected lamp power - lampPowerTolerance |
| ✓ lampVoltageTooHigh | Level of lamp voltage (not supply voltage) is greater than highLampVoltageThreshold. |
| ✓ lampVoltageTooLow | Level of lamp voltage (not supply voltage) is smaller than lowLampVoltageThreshold. |
| ✓ lampFailure | The lamp is not operating as it is supposed to (e.g. the lamp is broken). This event shall be used to detect a situation where the lamp (or LED module(s)) should be lit, but produce no light. This could be detected by the current flowing or power consumed. |
| ✓ dimmingFailure | The lamp is not dimming as it is supposed to (e.g. the driver is not connected properly). This event shall be used to detect a situation where the lamp (or LED module(s)) is lighting at a dimming level which is different from the expected dimming level, taking into account the programmed (or manual) level as well any correction (e.g. virtual power, constant light output). |
| ✓ currentTooHigh | Supply current is above the highCurrentThreshold defined in the lamp type. |
| ✓ currentTooLow | Supply current is below the lowCurrentThreshold defined in the lamp type. |
| ✓ powerFactorTooLow | The power factor is below powerFactorThreshold. |
| ✓ highTemperature | Indicates temperature is above the high threshold [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TemperatureSensorFunction.temperatureTooHigh instead.] |
| ✓ relayFailure | Set in case of internal relay is failing (e.g. it may be stuck in either on or off position). Typically if contactor error is used as well. |

| | |
|------------------------------|---|
| ✓ absolutLampPowerTooHigh | Indicates the power is above the lampPowerHighThreshold in the lamp type. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new absoluteLampPowerTooHigh instead.] |
| ✓ absolutLampPowerTooLow | Indicates the power is below the lampPowerLowThreshold in the lamp type. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new absoluteLampPowerTooLow instead.] |
| ✓ absoluteLampPowerTooHigh | Indicates the power is above the lampPowerHighThreshold in the lamp type |
| ✓ absoluteLampPowerTooLow | Indicates the power is below the lampPowerLowThreshold in the lamp type |
| ✓ controlGearCommFailure | Indicates failure of the control gear. |
| ✓ cyclingFailure | Indicates the lamp is constantly switching ON and OFF in an unexpected manner. This event shall be used to indicate a lamp which cycles while it should be on. The actual detection algorithm is outside the scope of this specification. |
| ✓ supplyLoss | Indicates loss of mains power. |
| ✓ contactorError | Indicates error in contactor |
| ✓ lampUnexpectedOn | Indicates lamp is unexpectedly on. |
| ✓ leakageDetected | Indicates that an earth leakage fault has been detected. |
| ✓ supplyVoltageTooHigh | Level of supply voltage is above the highLampVoltageThreshold. |
| ✓ supplyVoltageTooLow | Level of supply voltage is below the lowSupplyVoltageThreshold. |
| ✓ highSupplyVoltageThreshold | Supply voltage above which the supplyVoltageTooHigh event is triggered. |
| ✓ lowSupplyVoltageThreshold | Supply voltage below which the supplyVoltageTooLow event is triggered. |
| ✓ applicationType | Application Type of the lamp monitor depending on the use case. E.g.: LED Monitor |

Events

| # | Event type | Description |
|---|------------------|---|
| ✓ | lampPowerTooHigh | Lamp power is greater than expected lamp power + lampPowerTolerance |
| ✓ | lampPowerTooLow | Lamp power is smaller than expected lamp power - lampPowerTolerance |

| | |
|----------------------------|--|
| ✓ lampVoltageTooHigh | Level of lamp voltage (not supply voltage) is greater than highLampVoltageThreshold. |
| ✓ lampVoltageTooLow | Level of lamp voltage (not supply voltage) is smaller than lowLampVoltageThreshold. |
| ✓ currentTooHigh | Supply current is above the highCurrentThreshold defined in the lamp type |
| ✓ currentTooLow | Supply current is below the lowCurrentThreshold defined in the lamp type |
| ✓ powerFactorTooLow | The power factor is below powerFactorThreshold |
| ✓ lampFailure | The lamp is not operating as it is supposed to (e.g. the lamp is broken). This event shall be used to detect a situation where the lamp (or LED module(s)) should be lit, but produce no light. This could be detected by the current flowing or power consumed. |
| ✓ dimmingFailure | The lamp is not dimming as it is supposed to (e.g. the driver is not connected properly). This event shall be used to detect a situation where the lamp (or LED module(s)) is lighting at a dimming level which is different from the expected dimming level, taking into account the programmed (or manual) level as well any correction (e.g. virtual power, constant light output). |
| ✓ highTemperature | Indicates temperature is above the high threshold |
| ✓ relayFailure | Set in case of internal relay is failing |
| ✓ absoluteLampPowerTooHigh | Indicates the power is above the lampPowerHighThreshold in the lamp type |
| ✓ absoluteLampPowerTooLow | Indicates the power is below the lampPowerLowThreshold in the lamp type |
| ✓ controlGearCommFailure | Indicates failure of the control gear |
| ✓ cyclingFailure | Indicates the lamp is constantly switching ON and OFF in an unexpected manner |
| ✓ supplyLoss | Indicates loss of mains power |
| ✓ contactorError | Indicates error in contactor |
| ✓ lampUnexpectedOn | Indicates lamp is unexpectedly on |
| ✓ leakageDetected | Indicates that an earth leakage fault has been detected |
| ✓ supplyVoltageTooHigh | Level of supply voltage is above the highLampVoltageThreshold. |
| ✓ supplyVoltageTooLow | Level of supply voltage is below the lowSupplyVoltageThreshold. |

Electrical Meter

The electrical meter function supports electrical metering capabilities including measurements of voltage, current, power, energy, and power factor. This function may be associated with Luminaire Controllers, Cabinet Controllers or electrical meters installed in switch boxes. ODNs may implement both single phase and three phase meters. Typically meters within a control device will be single phase and stand-alone meters. A street side cabinet may have single phase or three phase meters.

Attributes

| # | Attribute | Description |
|---|-------------------------------|--|
| ✓ | totalPowerHighThreshold | Power above which the totalPowerTooHigh event is triggered. |
| ✓ | totalPowerLowThreshold | Power below which the totalPowerTooLow event is triggered. |
| ✓ | powerfactorThreshold | Power factor below which the powerfactorTooLow event is triggered. |
| ✓ | phase1PowerfactorLowThreshold | Phase 1 power factor below which the phase1PowerfactorTooLow event is triggered. |
| ✓ | phase2PowerfactorLowThreshold | Phase 2 power factor below which the phase2PowerfactorTooLow event is triggered. |
| ✓ | phase3PowerfactorLowThreshold | Phase 3 power factor below which the phase3PowerfactorTooLow event is triggered. |
| ✓ | supplyVoltageHighThreshold | Supply voltage above which the supplyVoltageTooHigh event is triggered. |
| ✓ | supplyVoltageLowThreshold | Supply voltage below which the supplyVoltageTooLow event is triggered. |
| ✓ | phase1VoltageHighThreshold | RMS voltage above which the phase1VoltageTooHigh event is triggered. |
| ✓ | phase1VoltageLowThreshold | RMS voltage below which the phase1VoltageTooLow event is triggered. |
| ✓ | phase2VoltageHighThreshold | RMS voltage above which the phase2VoltageTooHigh event is triggered. |
| ✓ | phase2VoltageLowThreshold | RMS voltage below which the phase2VoltageTooLow event is triggered. |
| ✓ | phase3VoltageHighThreshold | RMS voltage above which the phase3VoltageTooHigh event is triggered. |
| ✓ | phase3VoltageLowThreshold | RMS voltage below which the phase3VoltageTooLow event is triggered. |
| ✓ | totalCurrentHighThreshold | RMS current above which the currentTooHigh event is triggered. |
| ✓ | totalCurrentLowThreshold | RMS current below which the currentTooLow event is triggered. |
| ✓ | neutralCurrentHighThreshold | RMS current above which the neutralCurrentTooHigh event is triggered. |

| | |
|----------------------------------|--|
| ✓ phase1CurrentHighThreshold | RMS current above which the phase1CurrentTooHigh event is triggered. |
| ✓ phase1CurrentLowThreshold | RMS current below which the phase1CurrentTooLow event is triggered. |
| ✓ phase2CurrentHighThreshold | RMS current above which the phase2CurrentTooHigh event is triggered. |
| ✓ phase2CurrentLowThreshold | RMS current below which the phase2CurrentTooLow event is triggered. |
| ✓ phase3CurrentHighThreshold | RMS current above which the phase3CurrentTooHigh event is triggered. |
| ✓ phase3CurrentLowThreshold | RMS current below which the phase3CurrentTooLow event is triggered. |
| ✓ phase1ActivePowerHighThreshold | Power above which the phase1ActivePowerTooHigh event is triggered. |
| ✓ phase1ActivePowerLowThreshold | Power below which the phase1ActivePowerTooLow event is triggered. |
| ✓ phase2ActivePowerHighThreshold | Power above which the phase2ActivePowerTooHigh event is triggered. |
| ✓ phase2ActivePowerLowThreshold | Power below which the phase2ActivePowerTooLow event is triggered. |
| ✓ phase3ActivePowerHighThreshold | Power above which the phase3ActivePowerTooHigh event is triggered. |
| ✓ phase3ActivePowerLowThreshold | Power below which the phase3ActivePowerTooLow event is triggered. |
| ✓ totalPower | Sum of the active power consumed on phase 1, 2 and 3, or just the power for a single phase meter. |
| ✓ totalVA | Sum of the apparent power consumed on phase 1, 2 and 3, or just the apparent power for a single phase meter. |
| ✓ totalVAR | Sum of the reactive power consumed on phase 1, 2 and 3, or just the reactive power for a single phase meter. |
| ✓ maxDemandPower | Maximum peak power consumption. |
| ✓ totalActiveEnergy | Total cumulative kWh measured by the meter since installation date (or counter reset). |
| ✓ totalReactiveEnergy | Total cumulative kVarh measured by the meter since installation date (or counter reset). |
| ✓ totalApparentEnergy | Total cumulative kVAh measured by the meter since installation date (or counter reset). |
| ✓ frequency | Frequency on the line. |
| ✓ totalPowerFactor | Total active power divided by total apparent power. |

| | |
|--------------------------|--|
| ✓ totalPowerFactorSense | Sense of power factor (lead or lag). |
| ✓ phase1PowerFactor | Power factor on phase 1. |
| ✓ phase1PowerFactorSense | Sense of power factor (lead or lag). |
| ✓ phase2PowerFactor | Power factor on phase 2. |
| ✓ phase2PowerFactorSense | Sense of power factor (lead or lag). |
| ✓ phase3PowerFactor | Power factor on phase 3. |
| ✓ phase3PowerFactorSense | Sense of power factor (lead or lag). |
| ✓ supplyVoltage | Average between Phase1 RMS Voltage, Phase2 RMS Voltage and Phase3 RMS Voltage, or in the case of a single phase meter just the RMS supply voltage. |
| ✓ phase1Voltage | RMS Voltage between phase 1 and neutral. |
| ✓ phase2Voltage | RMS Voltage between phase 2 and neutral. |
| ✓ phase3Voltage | RMS Voltage between phase 3 and neutral. |
| ✓ voltagePhase1Phase2 | RMS Voltage between phase 1 and phase 2. |
| ✓ voltagePhase2Phase3 | RMS Voltage between phase 2 and phase 3. |
| ✓ voltagePhase3Phase1 | RMS Voltage between phase 3 and phase 1. |
| ✓ totalCurrent | Sum of the RMS currents on phase 1, 2 and 3. |
| ✓ averageCurrent | Average RMS current on phase 1, 2 and 3. |
| ✓ neutralCurrent | RMS current on neutral. |
| ✓ phase1Current | RMS current on phase 1. |
| ✓ phase2Current | RMS current on phase 2. |
| ✓ phase3Current | RMS current on phase 3. |
| ✓ phase1ActivePower | Active Power on phase 1. |
| ✓ phase2ActivePower | Active Power on phase 2. |
| ✓ phase3ActivePower | Active Power on phase 3. |
| ✓ phase1ApparentPower | Apparent Power on phase 1. |
| ✓ phase2ApparentPower | Apparent Power on phase 2. |
| ✓ phase3ApparentPower | Apparent Power on phase 3. |
| ✓ phase1ReactivePower | Reactive Power on phase 1. |
| ✓ phase2ReactivePower | Reactive Power on phase 2. |
| ✓ phase3ReactivePower | Reactive Power on phase 3. |
| ✓ phase1ActiveEnergy | Cumulative active energy on phase 1. |
| ✓ phase2ActiveEnergy | Cumulative active energy on phase 2. |
| ✓ phase3ActiveEnergy | Cumulative active energy on phase 3. |

| | |
|---------------------------|--|
| ✓ worstCurrentTHD | Worst value for Total Harmonic Distortion on current (all 3 phases). |
| ✓ phase1CurrentTHD | Total Harmonic Distortion on current for phase 1. |
| ✓ phase2CurrentTHD | Total Harmonic Distortion on current for phase 2. |
| ✓ phase3CurrentTHD | Total Harmonic Distortion on current for phase 3. |
| ✓ worstVoltageTHD | Worst Total Harmonic Distortion on voltage (all 3 phases). |
| ✓ averageVoltageTHD | Average value of Total Harmonic Distortion on voltage. |
| ✓ phase1VoltageTHD | Total Harmonic Distortion on voltage for phase 1. |
| ✓ phase2VoltageTHD | Total Harmonic Distortion on voltage for phase 2. |
| ✓ phase3VoltageTHD | Total Harmonic Distortion on voltage for phase 3. |
| ✓ phase1_2VoltageTHD | Total Harmonic Distortion on voltage between phase 1 and phase 2. |
| ✓ phase2_3VoltageTHD | Total Harmonic Distortion on voltage between phase 2 and phase 3. |
| ✓ phase3_1VoltageTHD | Total Harmonic Distortion on voltage between phase 3 and phase 1. |
| ✓ supplyLossCount | Incrementing count of supply losses. In the case of 3 phases the count of losses on all three phases together. The wrap around value is $2e32 - 1$. |
| ✓ phase1SupplyLossCount | Incrementing count of supply losses on Phase 1. The wrap around value is $2e32 - 1$. |
| ✓ phase2SupplyLossCount | Incrementing count of supply losses on Phase 2. The wrap around value is $2e32 - 1$. |
| ✓ phase3SupplyLossCount | Incrementing count of supply losses on Phase 3. The wrap around value is $2e32 - 1$. |
| ✓ totalPowerTooHigh | Indicates total power is above the totalPowerHighThreshold. |
| ✓ totalPowerTooLow | Indicates total power is below the totalPowerLowThreshold. |
| ✓ powerfactorTooLow | Indicates the power factor is below the powerfactorThreshold. |
| ✓ phase1PowerfactorTooLow | Indicates the phase 1 power factor is below the phase1PowerfactorLowThreshold. |
| ✓ phase2PowerfactorTooLow | Indicates the phase 2 power factor is below the phase2PowerfactorLowThreshold |
| ✓ phase3PowerfactorTooLow | Indicates the phase 3 power factor is below the phase3PowerfactorLowThreshold |

| | |
|----------------------------|---|
| ✓ supplyVoltageTooHigh | Indicates supply voltage is above the supplyVoltageHighThreshold. |
| ✓ supplyVoltageTooLow | Indicates supply voltage is below the supplyVoltageLowThreshold. |
| ✓ phase1VoltageTooHigh | Indicates phase 1 supply voltage is above the phase1VoltageHighThreshold. |
| ✓ phase1VoltageTooLow | Indicates phase 1 supply voltage is below the phase1VoltageLowThreshold. |
| ✓ phase2VoltageTooHigh | Indicates phase 2 supply voltage is above the phase2VoltageHighThreshold. |
| ✓ phase2VoltageTooLow | Indicates phase 2 supply voltage is below the phase2VoltageLowThreshold. |
| ✓ phase3VoltageTooHigh | Indicates phase 3 supply voltage is above the phase3VoltageHighThreshold. |
| ✓ phase3VoltageTooLow | Indicates phase 3 supply voltage is below the phase3VoltageLowThreshold. |
| ✓ totalCurrentTooHigh | Indicates the current is above the totalCurrentHighThreshold. |
| ✓ totalCurrentTooLow | Indicates the current is below the totalCurrentLowThreshold. |
| ✓ neutralCurrentTooHigh | Indicates the neutral current is above the neutralCurrentHighThreshold. |
| ✓ phase1CurrentTooHigh | Indicates the phase 1 current is above the phase1CurrentHighThreshold. |
| ✓ phase1CurrentTooLow | Indicates the phase 1 current is below the phase1CurrentLowThreshold. |
| ✓ phase2CurrentTooHigh | Indicates the phase 2 current is above the phase2CurrentHighThreshold. |
| ✓ phase2CurrentTooLow | Indicates the phase 2 current is below the phase2CurrentLowThreshold. |
| ✓ phase3CurrentTooHigh | Indicates the phase 3 current is above the phase3CurrentHighThreshold. |
| ✓ phase3CurrentTooLow | Indicates the phase 3 current is below the phase3CurrentLowThreshold. |
| ✓ phase1ActivePowerTooHigh | Indicates the phase 1 active power is above the phase1ActivePowerHighThreshold. |
| ✓ phase1ActivePowerTooLow | Indicates the phase 1 active power is below the phase1ActivePowerLowThreshold. |
| ✓ phase2ActivePowerTooHigh | Indicates the phase 2 active power is above the phase2ActivePowerHighThreshold. |

| | |
|----------------------------|---|
| ✓ phase2ActivePowerTooLow | Indicates the phase 2 active power is below the phase2ActivePowerLowThreshold. |
| ✓ phase3ActivePowerTooHigh | Indicates the phase 3 active power is above the phase3ActivePowerHighThreshold. |
| ✓ phase3ActivePowerTooLow | Indicates the phase 3 active power is below the phase3ActivePowerLowThreshold. |
| ✓ applicationType | Application Type of the electrical meter depending on the use case. E.g.: Lamp Electrical Meter, Segment Electrical Meter |
| ✓ supplyLoss | Indicates loss of supply (power). |

Events

| # | Event type | Description |
|---|--------------------------|--|
| ✓ | totalPowerTooHigh | Indicates total power is above the totalPowerHighThreshold |
| ✓ | totalPowerTooLow | Indicates total power is below the totalPowerLowThreshold |
| ✓ | powerFactorTooLow | talq.feature.event.ElectricalMeterFunction.powerFactorTooLow.desc |
| ✓ | supplyVoltageTooHigh | Indicates supply voltage is above the supplyVoltageHighThreshold |
| ✓ | supplyVoltageTooLow | Indicates supply voltage is below the supplyVoltageLowThreshold |
| ✓ | totalCurrentTooHigh | Indicates the current is above the totalCurrentHighThreshold |
| ✓ | totalCurrentTooLow | Indicates the current is below the totalCurrentLowThreshold |
| ✓ | neutralCurrentTooHigh | Indicates the neutral current is above the neutralCurrentHighThreshold |
| ✓ | phase1PowerfactorTooLow | Indicates the phase 1 power factor is below the phase1PowerfactorLowThreshold |
| ✓ | phase1VoltageTooHigh | Indicates phase 1 supply voltage is above the phase1VoltageHighThreshold |
| ✓ | phase1VoltageTooLow | Indicates phase 1 supply voltage is below the phase1VoltageLowThreshold |
| ✓ | phase1CurrentTooHigh | Indicates the phase 1 current is above the phase1CurrentHighThreshold |
| ✓ | phase1CurrentTooLow | Indicates the phase 1 current is below the phase1CurrentLowThreshold |
| ✓ | phase1ActivePowerTooHigh | Indicates the phase 1 active power is above the phase1ActivePowerHighThreshold |
| ✓ | phase1ActivePowerTooLow | Indicates the phase 1 active power is below the phase1ActivePowerLowThreshold |
| ✓ | phase2PowerfactorTooLow | Indicates the phase 2 power factor is below the phase2PowerfactorLowThreshold |

| | |
|----------------------------|--|
| ✓ phase2VoltageTooHigh | Indicates phase 2 supply voltage is above the phase2VoltageHighThreshold |
| ✓ phase2VoltageTooLow | Indicates phase 2 supply voltage is below the phase2VoltageLowThreshold |
| ✓ phase2CurrentTooHigh | Indicates the phase 2 current is above the phase2CurrentHighThreshold |
| ✓ phase2CurrentTooLow | Indicates the phase 2 current is below the phase2CurrentLowThreshold |
| ✓ phase2ActivePowerTooHigh | Indicates the phase 2 active power is above the phase2ActivePowerHighThreshold |
| ✓ phase2ActivePowerTooLow | Indicates the phase 2 active power is below the phase2ActivePowerLowThreshold |
| ✓ phase3PowerfactorTooLow | Indicates the phase 3 power factor is below the phase3PowerfactorLowThreshold |
| ✓ phase3VoltageTooHigh | Indicates phase 3 supply voltage is above the phase3VoltageHighThreshold |
| ✓ phase3VoltageTooLow | Indicates phase 3 supply voltage is below the phase3VoltageLowThreshold |
| ✓ phase3CurrentTooHigh | Indicates the phase 3 current is above the phase3CurrentHighThreshold |
| ✓ phase3CurrentTooLow | Indicates the phase 3 current is below the phase3CurrentLowThreshold |
| ✓ phase3ActivePowerTooHigh | Indicates the phase 3 active power is above the phase3ActivePowerHighThreshold |
| ✓ phase3ActivePowerTooLow | Indicates the phase 1 active power is below the phase2ActivePowerLowThreshold |
| ✓ supplyLoss | Indicates loss of supply (power). |

| | | |
|--|-------------------|--|
| Photocell | | |
| A Photocell function models the capabilities of a photocell that can be used for lighting control. This function shall be supported by the CMS and optionally by the ODNs (Gateway). | | |
| Attributes | | |
| # | Attribute | Description |
| ✓ | onLevel | Illuminance level at which the photocell switches to on state. |
| ✓ | offLevel | Illuminance level at which the photocell switches to off state. |
| ✓ | photocellOutput | Output state of the photocell. Possible values are ON (means the illuminance level has fallen below the onLevel) and OFF (means the illuminance level has risen above the offLevel). |
| ✓ | photocellOutputOn | The photocell output has changed to ON. |

- ✓ applicationType
- Application Type of the photocell depending on the use case. E.g.:
Presence detector

Events

| # | Event type | Description |
|---|-------------------|--|
| ✓ | photocellOutputOn | The photocell output has changed to ON |

Light Sensor

A Light Sensor function models the output of light sensor. This function is optional for both CMS and Gateway, but when supported the requirements in this section shall apply.

Attributes

| # | Attribute | Description |
|---|--------------------|---|
| ✓ | levelHighThreshold | Light level above which a levelTooHigh event is triggered. |
| ✓ | levelLowThreshold | Light level below which a levelTooLow event is triggered. |
| ✓ | lightLevel | Illuminance level. |
| ✓ | levelTooHigh | Indicates the light level is above the levelHighThreshold. |
| ✓ | levelTooLow | Indicates the light level is below the levelLowThreshold. |
| ✓ | applicationType | Application Type of the light sensor depending on the use case. E.g.: Day light detector |

Events

| # | Event type | Description |
|---|--------------|---|
| ✓ | levelTooHigh | Indicates the light level is above the levelHighThreshold |
| ✓ | levelTooLow | Indicates the light level is below the levelLowThreshold |

Binary Sensor

A Binary Sensor function can be used to model any sensor that provides a digital, binary output. This function is optional for both CMS and Gateway, but when supported the requirements in this section shall apply.

Attributes

| # | Attribute | Description |
|---|-----------------|--|
| ✓ | level | Sensor Output level. |
| ✓ | sensorOutputOn | Indicates the sensor output changed to ON. |
| ✓ | applicationType | Application Type of the binary sensor depending on the use case. E.g.: Door opened sensor |

Events

| # | Event type | Description |
|---|----------------|---|
| ✓ | sensorOutputOn | Indicates the sensor output changed to ON |

Generic Sensor

A Generic Sensor function can be used to model any sensor that provides an analog or multilevel output. This function is optional for both CMS and Gateway, but when supported the requirements in this section shall apply.

Attributes

| # | Attribute | Description |
|---|--------------------|---|
| ✓ | levelHighThreshold | Threshold above which a levelTooHigh event is triggered. |
| ✓ | levelLowThreshold | Threshold below which a levelTooLow event is triggered. |
| ✓ | level | Sensor Output level. |
| ✓ | levelTooHigh | Indicates the sensor output level is above the levelHighThreshold. |
| ✓ | levelTooLow | Indicates the sensor output level is below the levelLowThreshold. |
| ✓ | applicationType | Application Type of the generic sensor depending on the use case. E.g.: Sound sensor |

Events

| # | Event type | Description |
|---|--------------|---|
| ✓ | levelTooHigh | Indicates the sensor output level is above the levelHighThreshold |
| ✓ | levelTooLow | Indicates the sensor output level is below the levelLowThreshold |

Generic Actuator

The Generic Actuator function includes attributes related to generic control and it represents the smallest unit for control purposes.

Attributes

| # | Attribute | Description |
|---|-----------------|---|
| ✓ | defaultState | Sets the default state output for the generic actuator. This shall be applicable if no other command is active. |
| ✓ | actualState | This attribute should reflect the physical state of the source as much as possible. It may be calculated or measured, depending on the specific ODN implementation, which is outside the scope of this specification. |
| ✓ | targetCommand | Latest command for the generic actuator. |
| ✓ | feedbackCommand | This attribute reflects the command in effect and it might deviate from the actualState due to propagation time or due to internal ODN specific mechanisms to handle the priority of the requests. |

| | |
|-----------------------|--|
| ✓ stateChange | The state has changed. |
| ✓ calendarID | TALQ Address of the calendar controlling this generic actuator. If this attribute is empty, the behavior shall be determined by the ODN. If the attribute is invalid, the ODN shall trigger a generic invalid address event and the behavior shall be determined by the ODN. |
| ✓ invalidCalendar | This event is generated when a calendar has been allocated and can not be implemented it. |
| ✓ invalidProgram | This event is generated when a control program has been allocated and can not be implemented it. |
| ✓ programChange | This event is generated when the control program applicable to the actuator has changed. |
| ✓ calendarChange | This event is generated when the calendar applicable to the actuator has changed. |
| ✓ targetCommandChange | This event is generated when the targetCommand has changed. |
| ✓ applicationType | Application Type of the generic actuator depending on the use case. E.g.: Water valve |

Events

| # | Event type | Description |
|---|---------------------|--|
| ✓ | stateChange | The state has changed. |
| ✓ | invalidCalendar | This event is generated when a calendar has been allocated and can not be implemented it. |
| ✓ | invalidProgram | This event is generated when a control program has been allocated and can not be implemented it. |
| ✓ | programChange | This event is generated when the control program applicable to the actuator has changed. |
| ✓ | calendarChange | This event is generated when the calendar applicable to the actuator has changed. |
| ✓ | targetCommandChange | This event is generated when the targetCommand has changed. |

Temperature Sensor

The Temperature Sensor function allows a CMS to monitor the temperature in a device and send events in case the value is above/below configurable thresholds.

Attributes

| # | Attribute | Description |
|---|--------------------------|--|
| ✓ | temperatureHighThreshold | Threshold above which a temperatureTooHigh event is triggered. |

| | |
|----------------------------|---|
| ✓ temperatureLowThreshold | Threshold below which a temperatureTooLow event is triggered. |
| ✓ fireDetectionThreshold | Threshold above which a fireDetected event is triggered. |
| ✓ temperature | Output temperature. |
| ✓ temperatureTooHigh | Indicates the output temperature is above the temperatureHighThreshold. |
| ✓ temperatureTooLow | Indicates the output temperature is below the temperatureLowThreshold. |
| ✓ fireDetected | Indicates the output temperature is above the fireDetectionThreshold. |
| ✓ applicationType | Application Type of the temperature depending on the use case. E.g.: Solar Battery Charger or Lamp |
| ✓ minMeasuredTemperature | The minimum value measured by the sensor since power ON or since measuredTemperatureSince. |
| ✓ maxMeasuredTemperature | The maximum value measured by the sensor since power ON or since measuredTemperatureSince. |
| ✓ measuredTemperatureSince | Indicates the date and time at which measuredTemperature is reset to zero. The Gateway may change this value with the actual one depending on implementation. |

Events

| # | Event type | Description |
|---|--------------------|---|
| ✓ | temperatureTooHigh | Indicates the output temperature is above the temperatureHighThreshold. |
| ✓ | temperatureTooLow | Indicates the output temperature is below the temperatureLowThreshold. |
| ✓ | fireDetected | Indicates the output temperature is above the fireDetectionThreshold. |

Humidity Sensor

The Humidity Sensor function allows a CMS to monitor the humidity in a device and send events in case the value is above/below configurable thresholds.

Attributes

| # | Attribute | Description |
|---|-----------------------|---|
| ✓ | humidityLowThreshold | talq.feature.attribute.HumiditySensorFunction.humidityLowThreshold.desc |
| ✓ | humidityHighThreshold | Threshold above which a humidityTooHigh event is triggered. |
| ✓ | humidity | Output humidity. |
| ✓ | humidityTooLow | talq.feature.attribute.HumiditySensorFunction.humidityTooLow.desc |
| ✓ | humidityTooHigh | Indicates the output humidity is above the humidityHighThreshold. |

- ✓ applicationType
- Application Type of the humidity sensor depending on the use case. E.g.:
Air Humidity Sensor

Events

| # | Event type | Description |
|---|-----------------|---|
| ✓ | humidityTooHigh | Indicates the output humidity is above the humidityHighThreshold. |

Particulate Matter Sensor

The Particulate Matter Sensor function allows a CMS to monitor the PM10, PM2.5 and PM1 in a device and send events in case the value is above/below configurable thresholds.

Attributes

| # | Attribute | Description |
|---|--------------------|---|
| ✓ | pm1HighThreshold | Threshold (micrograms/m3) above which a pm1TooHigh event is triggered. |
| ✓ | pm2-5HighThreshold | Threshold (micrograms/m3) above which a pm2-5TooHigh event is triggered. |
| ✓ | pm10HighThreshold | Threshold (micrograms/m3) above which a pm10TooHigh event is triggered. |
| ✓ | pm1 | Level of pm1 measured by the sensor. (micrograms/m3) |
| ✓ | pm2-5 | Level of pm2-5 measured by the sensor. (micrograms/m3) |
| ✓ | pm10 | Level of pm10 measured by the sensor. (micrograms/m3) |
| ✓ | pm1TooHigh | Indicates the output pm1 is above the pm1HighThreshold. |
| ✓ | pm2-5TooHigh | Indicates the output pm2-5 is above the pm2-5HighThreshold. |
| ✓ | pm10TooHigh | Indicates the output pm10 is above the pm10HighThreshold. |
| ✓ | applicationType | Application Type of the particulate matter sensor depending on the use case. E.g.: 'Air Quality Sensor' |
| ✓ | pm1-24hAverage | Average level of pm1 measured by the sensor during the last 24h. (micrograms/m3) |
| ✓ | pm2-5-24hAverage | Average level of pm2.5 measured by the sensor during the last 24h. (micrograms/m3) |
| ✓ | pm10-24hAverage | Average level of pm10 measured by the sensor during the last 24h. (micrograms/m3) |

Events

| # | Event type | Description |
|---|--------------|---|
| ✓ | pm1TooHigh | Indicates the output pm1 is above the pm1HighThreshold. |
| ✓ | pm2-5TooHigh | Indicates the output pm2-5 is above the pm2-5HighThreshold. |

- ✓ pm10TooHigh Indicates the output pm10 is above the pm10HighThreshold.

Presence Sensor

The Presence Sensor function allows a CMS to detect presence. This function may be used in Parking Place detectors as well as in dynamic outdoor lighting scenario.

Attributes

| # | Attribute | Description |
|---|-----------------------|--|
| ✓ | presenceStatus | Presence status. |
| ✓ | presenceStatusChanged | Indicates the presence status changed. |
| ✓ | applicationType | Application Type of the presence sensor depending on the use case. E.g.: Presence detector |

Events

| # | Event type | Description |
|---|-----------------------|--|
| ✓ | presenceStatusChanged | Indicates the presence status changed. |

Movement Sensor

The Movement Sensor function allows a CMS to detect movement. This function may be used in a Waste Container sensor to detect that container gets emptied or is not in the proper position, as well as in asset tracking applications.[DEPRECATED: This function has been deprecated and it will be removed in the next MAJOR release. Please use the new LocationSensorFunction instead.]

Attributes

| # | Attribute | Description |
|---|---------------------|--|
| ✓ | movementThreshold | Threshold above which a movementDetected event is triggered. |
| ✓ | movementDetected | Indicates the movement is above the movementThreshold. |
| ✓ | notInProperPosition | Indicates the sensor is not in proper position. |

Events

| # | Event type | Description |
|---|---------------------|--|
| ✓ | movementDetected | Indicates the movement is above the movementThreshold. |
| ✓ | notInProperPosition | Indicates the sensor is not in proper position. |

Battery Level Sensor

The Battery Level Sensor function allows to measure the charge of the battery, monitor the battery and send events in case the value is above/below configurable thresholds.

Attributes

| # | Attribute | Description |
|---|--------------------------|---|
| ✓ | powerSource | The power source of battery. |
| ✓ | batteryLevelLowThreshold | Threshold below which a batteryLevelTooLow event is triggered. |
| ✓ | batteryLevel | Battery level. |
| ✓ | batteryLevelTooLow | Indicates the battery level is below the batteryLevelLowThreshold. |
| ✓ | applicationType | Application Type of the battery level sensor depending on the use case. E.g.: Solar Battery |

Events

| # | Event type | Description |
|---|--------------------|---|
| ✓ | batteryLevelTooLow | talq.feature.event.BatteryLevelSensorFunction.batteryLevelTooLow.desc |

Filling Level Sensor

The Filling Level Sensor function allows to measure how full a container is and send events in case the value is above/below configurable thresholds.

Attributes

| # | Attribute | Description |
|---|--------------------|--|
| ✓ | levelHighThreshold | Threshold (m) above which a fillingHeight event is triggered. |
| ✓ | containerHeight | Container height (m). |
| ✓ | containerVolume | Container volume (m ³). |
| ✓ | fillingHeight | Filling container height (m). |
| ✓ | fillingPercentage | Filling percentage. |
| ✓ | containerFull | Indicates the container filling height is above levelHighThreshold. |
| ✓ | contentsType | Indicates de type of contents in the container. Some technologies, such as ultrasonic sensors, need this information in order to measeure accuratelly. Possible values are: mixed waste, organic, paper, plastics, glass, liquid, clothing, electronics, metal or other. If other is selected, then contentsOtherType shall be used. |
| ✓ | contentsOtherType | Type of contents if it is not included in the Enum list of contents for contentsType. |
| ✓ | applicationType | Application Type of the filling level sensor depending on the use case. E.g.: Container Filling Level |

Events

| # | Event type | Description |
|---|------------|-------------|
|---|------------|-------------|

✓ containerFull

Indicates the container filling height is above levelHighThreshold.

Solar Battery Charger*

A solar battery charger is used to charge a battery with solar energy. Typical use cases are energy demanding off-grid applications like solar lighting, solar vehicle charging (cars and bikes), public transit information, traffic control, public security (CCTV) and many more.

Attributes

| # | Attribute | Description |
|---|--------------------------|--|
| ✓ | inputVoltage | Measured DC voltage of the charger input (V). |
| ✓ | inputCurrent | Measured DC current of the charger input (A). |
| ✓ | outputVoltage | Output voltage (V). |
| ✓ | outputCurrent | Output current (A). |
| ✓ | chargerTemperature | Measured temperature of the charger circuit (C). [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TemperatureSensorFunction.temperature with applicationType=Charger instead.] |
| ✓ | PVTemperature | Measured temperature of the attached photovoltaic module (C). [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TemperatureSensorFunction.temperature with applicationType=PVT instead.] |
| ✓ | accumulatedEnergy | Accumulated energy yield since accumulatedSince (Wh). |
| ✓ | startChargeInputVoltage | Configuration parameter to set input voltage thresholds at different temperatures at which the battery charger shall start charging the battery (V, C). The values are stored as a list of KVPs (Key-Value Pair), where the key is the temperature and the value is the voltage. |
| ✓ | endChargeInputVoltage | Configuration parameter to set input voltage thresholds at different temperatures at which the battery charger shall cease charging the battery (V, C). The values are stored as a list of KVPs (Key-Value Pair), where the key is the temperature and the value is the voltage. |
| ✓ | highTemperatureThreshold | Threshold above which the highTemperature event is triggered (C). [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TemperatureSensorFunction.temperatureTooHighThreshold instead.] |

| | |
|---------------------------|---|
| ✓ lowTemperatureThreshold | Threshold above which the lowTemperature event is triggered (C). [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TemperatureSensorFunction.temperatureTooLowThreshold instead.] |
| ✓ highPowerThreshold | Threshold above which the highPower event is triggered (W). |
| ✓ accumulatedSince | Indicates the date and time at which accumulatedEnergy is reset to zero. The Gateway may change this value with the actual one depending on implementation. |
| ✓ highTemperature | Indicates the measured temperature is above the high temperature threshold. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TemperatureSensorFunction.temperatureTooHigh instead.] |
| ✓ lowTemperature | Indicates the measured temperature is below the low temperature threshold. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TemperatureSensorFunction.temperatureTooLow instead.] |
| ✓ highPower | Indicates the power exceeds highPowerThreshold. |
| ✓ charging | Indicates whether the battery is being charged. |
| ✓ applicationType | Application Type of the solar battery charger depending on the use case. E.g.: Lamp Battery |

Events

| # | Event type | Description |
|---|-----------------|---|
| ✓ | highTemperature | Indicates the measured temperature is above the high temperature threshold. |
| ✓ | lowTemperature | Indicates the measured temperature is below the low temperature threshold. |
| ✓ | highPower | Indicates the power exceeds highPowerThreshold. |
| ✓ | charging | Indicates whether the battery is being charged. |

Battery Management System*

A battery management system is used to monitor the charging and discharging of a battery and protect the battery. Typical use cases are (off-grid) applications like solar lighting, solar vehicle charging (cars and bikes), public transit information, traffic control, public security (CCTV) and many more, where the battery is charged and discharged on a regular basis.

Attributes

| # | Attribute | Description |
|---|-----------|-------------|
|---|-----------|-------------|

| | |
|-----------------------------------|--|
| ✓ batteryChemistry | Attribute to define the battery chemistry. (e.g.: Lead Acid, Lithium-Iron-Phosphate (LiFePO4), Nickel-Metal-Hydrid (NiMH), Lithium-Titanate-Oxide (LTO), ...) |
| ✓ nominalVoltage | Attribute to set the nominal voltage of the battery in V (at room temperature). This can be used to calculate the capacity and to configure the BMS. |
| ✓ nominalCapacity | Attribute to set the nominal capacity of the battery in Ah (at room temperature). |
| ✓ batteryVoltage | Measurement of the battery voltage in V |
| ✓ batteryCurrent | Measurement of the battery current in A. This value can be negative due to polarity. |
| ✓ batteryLevel | Percentage |
| ✓ estimatedCapacity | This attribute gives an estimated remaining capacity of the battery in Ah. This depends very much on the wear and age of the battery. |
| ✓ temperature | Temperature at the battery in C. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TemperatureSensorFunction.temperature with applicationType=Battery instead.] |
| ✓ batteryEOCVoltageTemperatureMap | End of charge voltages (V) of the battery for various temperatures (C) |
| ✓ batteryEODVoltageTemperatureMap | End of discharge voltages (V) of the battery for various temperatures (C) |
| ✓ batteryFullThreshold | Level threshold to indicate that the battery is full. |
| ✓ batteryEmptyThreshold | Level threshold to indicate that the battery is empty. |
| ✓ overCurrentChargeThreshold | Maximum charge current threshold (A) |
| ✓ overCurrentDischargeThreshold | Maximum discharge current threshold (A) |
| ✓ highTemperatureThreshold | Threshold above which the highTemperature event is triggered (C). [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TemperatureSensorFunction.temperatureTooHighThreshold instead.] |
| ✓ batteryFull | Indicates that the battery is full. |
| ✓ batteryEmpty | Indicates that the battery is empty. |
| ✓ overCurrentCharge | Indicates that the charge current is higher than the threshold. |
| ✓ overCurrentDischarge | Indicates that the discharge current is higher than the threshold. |

- ✓

highTemperature

Indicates that the measured temperature is higher than the threshold. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TemperatureSensorFunction.temperatureTooHigh instead.]
- ✓

applicationType

Application Type of the battery management system depending on the use case. E.g.: Lamp Battery

Events

| # | Event type | Description |
|---|----------------------|---|
| ✓ | batteryFull | Indicates that the battery is full. |
| ✓ | batteryEmpty | Indicates that the battery is empty. |
| ✓ | overCurrentCharge | Indicates that the charge current is higher than the threshold. |
| ✓ | overCurrentDischarge | Indicates that the discharge current is higher than the threshold. |
| ✓ | highTemperature | Indicates that the measured temperature is higher than the threshold. |

Traffic Counter*

The Traffic Counter Function is used to provide statistics on the number of vehicles passing on the road. It allows to have the number of pedestrians, bicycles, cars or trucks for a certain period of time that is configurable by the CMS. It also allows to count the number of vehicles using diesel or petrol.

Attributes

| # | Attribute | Description |
|---|-------------------------------|---|
| ✓ | roadUserNumber | Number of road users of the specified type detected over the sampling period. |
| ✓ | accumulatedRoadUserNumber | measurement Number of road users of the specified type detected since accumulatedSince. |
| ✓ | roadUser | Type of road user (pedestrian, bicycle, motorcycle, car, truck, diesel vehicle, petrol vehicle, electric vehicle, scooter, others). |
| ✓ | accumulatedSince | Indicates the date and time at which accumulatedRoadUserNumber is reset to zero. The Gateway may change this value with the actual one depending on implementation. |
| ✓ | heavyTrafficDetected | Triggered if the traffic measured over the sampling period is above heavyTrafficDetectedThreshold. |
| ✓ | heavyTrafficDetectedThreshold | Threshold above which heavyTrafficDetected is triggered. |
| ✓ | trafficSamplingPeriod | Used by heavyTrafficDetected and roadUserNumber. In seconds. |

| | |
|-----------------------------|---|
| ✓ averageSpeed | Average speed measured on the road users of the specified type during the last sampling period (km/h) |
| ✓ averageDistance | Average distance between two road users of the specified type during the last sampling period (m) |
| ✓ speedLimitThreshold | Speed limit threshold used to calculate the percentage of road users of the specified type above speed limit. (km/h) |
| ✓ percentageAboveSpeedLimit | Percentage of road users of the specified type driving above speed limit detected over the sampling period. |
| ✓ applicationType | Application Type of the traffic counter depending on the use case. E.g.: 'People counter; Vehicle counter' |
| ✓ actualUserNumber | Number of road users currently identified by the device |
| ✓ sensorType | Type of sensor (e.g: Bluetooth beacon, WIFI detector) |
| ✓ dailyRoadUserNumber | Cumulated number of road users detected by the device since beginning of the day. |
| ✓ minSpeed | Minimum cutoff speed under which traffic is not measured (km/h) |
| ✓ maxSpeed | Maximum cutoff speed above which traffic is not measured (km/h) |
| ✓ sensorSensitivity | Sensor sensitivity (%) to reduce sensor detection range. This value must be the same when multiple instances of the function are used for the same physical sensor. |
| ✓ trafficDirection | Specifies whether the sensor measures only incoming traffic, outgoing traffic, or both. (Direction 1, Direction 2, Both) |

Events

| # | Event type | Description |
|---|----------------------|--|
| ✓ | heavyTrafficDetected | Triggered if the traffic measured over the sampling period is above heavyTrafficDetectedThreshold. |

Location Sensor*

The Location Sensor Function is used to indicate that an object has changed position attributes configurable by the CMS or based on internal setup of the vendor. For example, a specific location (latitude, longitude) of a device could be defined by the vendor. If the device is equipped with a GPS, it could send a specific event indicating that its position is different to the one defined by the CMS. We might also want to let the configuration to the vendor itself and simply define events notifying the CMS that the default configuration has changed. For example, a garbage bin could have its location defined based on a sensor placed on the floor. If the bin is not above this sensor, the vendor will trigger an event. In this last case, the CMS does not need to configure anything.

Attributes

| # | Attribute | Description |
|---|-----------|-------------|
|---|-----------|-------------|

| | |
|----------------------------|--|
| ✓ expectedLocation | Nominal location of the device |
| ✓ locationChangedThreshold | Distance (meters) |
| ✓ location | Location of the device |
| ✓ locationChanged | Triggered when the difference between location and expectedLocation is above locationChangedThreshold |
| ✓ uncertainty | This uncertainty indicates the radius of a circular area in meters, reported by the positioning system. The circular area is used to describe uncertainty about a point for coordinates in a two-dimensional coordinate reference systems (CRS). The center point of a circular area is specified by using the Latitude and the Longitude Resources. |
| ✓ compassDirection | The measured compass direction. 0..360 deg. |
| ✓ velocity | The instantaneous velocity of the device, as defined in [3GPP-TS_23.032]. The AttributeVelocity contains horizontal speed, bearing, vertical speed, direction and uncertainty. |
| ✓ speed | The instantaneous speed is the time rate of change in position of the device without regard for direction: the scalar component of velocity in 3d. (m/s) |
| ✓ applicationType | Application Type of the location sensor depending on the use case. E.g.: Pole Location |

Events

| # | Event type | Description |
|---|-----------------|---|
| ✓ | locationChanged | Triggered when the difference between location and expectedLocation is above locationChangedThreshold |

Accelerometer*

The Accelerometer Function is used to indicate that an object has had an impact with another object and to report its acceleration.

Attributes

| # | Attribute | Description |
|---|-------------------------------------|--|
| ✓ | impactDetectedAccelerationThreshold | Threshold for acceleration above which impactDetected is triggered (g) |
| ✓ | accelerationSamplingPeriod | In seconds |
| ✓ | accelerationX | Maximum acceleration on the X axis (g) over accelerationSamplingPeriod |
| ✓ | accelerationY | Maximum acceleration on the Y axis (g) over accelerationSamplingPeriod |

| | |
|-------------------|---|
| ✓ accelerationZ | Maximum acceleration on the Z axis (g) over accelerationSamplingPeriod |
| ✓ acceleration | Maximum acceleration of the device (g) over accelerationSamplingPeriod |
| ✓ impactDetected | Indicates that the acceleration is above impactDetectedAccelerationThreshold |
| ✓ applicationType | Application Type of the accelerometer depending on the use case. E.g.: Crash detector |

Events

| # | Event type | Description |
|---|----------------|--|
| ✓ | impactDetected | Indicates that the acceleration is above impactDetectedAccelerationThreshold |

Orientation*

The Orientation function is used to indicate that an object has changed orientation based on attributes configurable by the CMS or based on internal setup of the vendor. The target orientation of the object could be configured by the CMS or could be handled by the vendor. In the latter case, the configuration is let to the vendor itself and events are triggered depending on internal configuration.

Attributes

| # | Attribute | Description |
|---|-----------------------------|---|
| ✓ | expectedOrientation | Nominal orientation of the device |
| ✓ | orientationChangedThreshold | Threshold above which orientationChanged is triggered |
| ✓ | orientation | Orientation of the device |
| ✓ | orientationChanged | Triggered when orientation differs from expectedOrientation by more than orientationChangedThreshold on any angle, or when the device determines itself that its orientation has changed. |
| ✓ | applicationType | Application Type of the orientation depending on the use case. E.g.: Orientation change detector |

Events

| # | Event type | Description |
|---|--------------------|---|
| ✓ | orientationChanged | Triggered when orientation differs from expectedOrientation by more than orientationChangedThreshold on any angle, or when the device determines itself that its orientation has changed. |

Fluid Level Sensor*

The Fluid Level Sensor function allows to collect data and events about fluid levels. It could be used to measure fluid levels in channels, lakes, containers, etc.

Attributes

| # | Attribute | Description |
|---|----------------------------|---|
| ✓ | fluidLevelTooHighThreshold | Threshold above which fluidLevelTooHighThreshold is triggered. In meters |
| ✓ | fluidLevelTooLowThreshold | Threshold below which fluidLevelTooLowThreshold is triggered. In meters |
| ✓ | distanceSensorBottom | Distance between the sensor and the bottom of the channel, lake, container, etc. In meters |
| ✓ | fluidLevel | Fluid level in meters |
| ✓ | fluidLevelTooHigh | Triggered when fluidLevel is above fluidLevelTooHighThreshold |
| ✓ | fluidLevelTooLow | Triggered when fluidLevel is below fluidLevelTooLowThreshold |
| ✓ | applicationType | Application Type of the fluid level sensor depending on the use case. E.g.: Lake level sensor |

Events

| # | Event type | Description |
|---|-------------------|---|
| ✓ | fluidLevelTooHigh | Triggered when fluidLevel is above fluidLevelTooHighThreshold |
| ✓ | fluidLevelTooLow | Triggered when fluidLevel is below fluidLevelTooLowThreshold |

Waste Container*

The Waste Container function allows to log when the container is collected and send events in case the date is above a configurable thresholds. Additionlly it sends events when the contents or container are tampered.

Attributes

| # | Attribute | Description |
|---|-------------------------|---|
| ✓ | lastCollectionDate | Last collection date. |
| ✓ | collectionLateThreshold | Threshold (days) since last collection date above which a collection late event is triggered. |
| ✓ | collectionLate | Indicates that the number of days occured since the lastCollectionDate is over the collectionLateThreshold. |
| ✓ | containerTampered | Indicates that the container is being tampered, or some parts are being removed. |
| ✓ | contentsTampered | Indicates that the contents are being tampered or stolen. |
| ✓ | wasteType | Indicates de type of waste in the container. Possible values are: mixed waste, organic, paper, plastics, glass, liquid, clothing, electronics, metal or other. If other is selected, then wasteOtherType shall be used. |

| | |
|-------------------|--|
| ✓ wasteOtherType | Type of waste if it is not included in the Enum list of contents for wasteType. |
| ✓ applicationType | Application Type of the waste container depending on the use case. E.g.: Waste container |

Events

| # | Event type | Description |
|---|-------------------|--|
| ✓ | containerTampered | Indicates that the container is being tampered, or some parts are being removed. |
| ✓ | contentsTampered | Indicates that the contents are being tampered or stolen. |

pH Sensor*

The pH Sensor allows to measure the pH and sends events if the value is above/below the configured thresholds.

Attributes

| # | Attribute | Description |
|---|----------------------|---|
| ✓ | pH | pH value. |
| ✓ | pHHighLevelThreshold | Threshold above which a pHTooHigh (too Alkaline) event is triggered. |
| ✓ | pHLowLevelThreshold | Threshold below which a pHTooLow (too Acidic) event is triggered. |
| ✓ | pHTooHigh | Indicates the pH measure is above the pHHighLevelThreshold, that is too alkaline. |
| ✓ | pHTooLow | Indicates the pH measure is below the pHLowLevelThreshold, that is too acidic. |
| ✓ | applicationType | Application Type of the pH sensor depending on the use case. E.g.: Hazardous Waste Detector |

Events

| # | Event type | Description |
|---|------------|---|
| ✓ | pHTooHigh | Indicates the pH measure is above the pHHighLevelThreshold, that is too alkaline. |
| ✓ | pHTooLow | Indicates the pH measure is below the pHLowLevelThreshold, that is too acidic. |

Weight Sensor*

The Weight Sensor function allows a CMS to monitor the weight in a device and send events in case the value is above/below configurable thresholds.

Attributes

| # | Attribute | Description |
|---|---------------------|---|
| ✓ | weightLowThreshold | Threshold (in kg) below which a weightTooLow event is triggered. |
| ✓ | weightHighThreshold | Threshold (in kg) above which a weightTooHigh event is triggered. |
| ✓ | weight | Output weight in kg. |
| ✓ | weightTooLow | Indicates the output weight is below the weightLowThreshold. |
| ✓ | weightTooHigh | Indicates the output weight is above the weightHighThreshold. |
| ✓ | applicationType | Application Type of the weight sensor depending on the use case. E.g.: Waste Weight Detector |

Events

| # | Event type | Description |
|---|---------------|---|
| ✓ | weightTooLow | Indicates the output weight is below the weightLowThreshold. |
| ✓ | weightTooHigh | Indicates the output weight is above the weightHighThreshold. |

Gas Sensor*

The Gas Sensor function allows to measure the gas concentration and sends events if the level is above the configured thresholds.

Attributes

| # | Attribute | Description |
|---|-------------------------------|--|
| ✓ | gasConcentration | Gas concentration (ppm) |
| ✓ | gasHighConcentrationThreshold | Threshold (ppm) above which a gasConcentrationTooHigh event is triggered. |
| ✓ | gasConcentrationTooHigh | Indicates that the gasConcentration is above the gasHighConcentrationThreshold. |
| ✓ | gasName | Type of gas: CO, CO2, O2, O3, NO, NO2, SO2, NH3, CH4, H2, H2S, HCl, HCN, PH3, ETO, Other. If Other is selected, then gasOtherName shall be used. |
| ✓ | gasOtherName | Type of gas if it is not included in the Enum list of gases for gasName |
| ✓ | applicationType | Application Type of the gas sensor depending on the use case. E.g.: 'Waste Gas Detector' |
| ✓ | gasConcentration1hAverage | Average concentration of gas measured by the sensor during the last 1 hour. (ppm) |
| ✓ | gasConcentration8hAverage | Average concentration of gas measured by the sensor during the last 8 hours. (ppm) |

Events

| # | Event type | Description |
|---|-------------------------|---|
| ✓ | gasConcentrationTooHigh | Indicates that the gasConcentration is above the gasHighConcentrationThreshold. |

Simple Actuator

The Simple Actuator function includes attributes related to generic control and it represents the smallest unit for control purposes.

Attributes

| # | Attribute | Description |
|---|---------------------|---|
| ✓ | defaultState | Sets the default state output for the simple actuator. This shall be applicable if the actuator is not under an override control (OverrideCommand). |
| ✓ | actualState | This attribute should reflect the physical state of the source as much as possible. It may be calculated or measured, depending on the specific ODN implementation, which is outside the scope of this specification. |
| ✓ | targetCommand | Latest command for the simple actuator. |
| ✓ | feedbackCommand | This attribute reflects the command in effect and it might deviate from the actualState due to propagation time or due to internal ODN specific mechanisms to handle the priority of the requests. |
| ✓ | stateChange | The state has changed. |
| ✓ | targetCommandChange | This event is generated when the targetCommand has changed. |
| ✓ | applicationType | Application Type of the simple actuator depending on the use case. E.g.: Water valve |

Events

| # | Event type | Description |
|---|---------------------|---|
| ✓ | stateChange | The state has changed. |
| ✓ | targetCommandChange | This event is generated when the targetCommand has changed. |

Time*

The Time function includes attributes related to generic control and it represents the smallest unit for control purposes.

Attributes

| # | Attribute | Description |
|---|-----------|-------------|
|---|-----------|-------------|

| | |
|------------------|--|
| ✓ timeZone | Time zone of the device. Time zone may be expressed in two formats. where is a time zone as defined in the zone.tab of the IANA timezone database [IANA]; and stdoffset[dst[offset]][,start[/time],en d[/time]]] as defined by the Open Group for posix systems [POSIX]. |
| ✓ ntpServers | List of NTP servers to use for time synchronization (Hostname or IP address). |
| ✓ ntpSynchPeriod | Number of hours between two time synchronization updates. |
| ✓ currentTime | Current time of the device defined as local time with time zone designator. |
| ✓ lastTimeSync | Last time at which a successful time synchronization occurred. |
| ✓ lastSyncError | Set to True in case the latest time synchronization operation failed. Set to False in case the last operation succeeded. |

Events

| # | Event type | Description |
|---|---------------|--|
| ✓ | lastSyncError | This event is generated when the latest time synchronization operation failed. |

Segment Monitor*

The Segment Monitor function enables monitoring of segment parameters. Multiple segment monitor functions may be implemented by a single device.

Attributes

| # | Attribute | Description |
|---|-----------------------|---|
| ✓ | applicationType | Application Type of the segment monitor depending on the use case. E.g.: "Road Lighting, Architecture Lighting" |
| ✓ | segmentReference | Reference of the segment monitor depending on the use case. E.g.: "Segment A1" |
| ✓ | numberOfLoads | Number of loads being monitored by the segment monitor function. |
| ✓ | switchingErrorOn | Indicates error in switching circuit. For instance, if a contactor or relay is used, it may be stuck in ON position. |
| ✓ | switchingErrorOff | Indicates error in switching circuit. For instance, if a contactor or relay is used, it may be stuck in OFF position. |
| ✓ | leakageDetected | Indicates that an earth leakage fault has been detected. |
| ✓ | cabinetDoorOpen | Cabinet door is open. |
| ✓ | circuitBreakerTripped | Indicates that the circuit breaker has tripped |
| ✓ | localOverride | Indicates that there is a local override (ON, OFF) or no override |

Events

| # | Event type | Description |
|---|-----------------|-----------------------|
| ✓ | cabinetDoorOpen | Cabinet door is open. |

| | |
|-------------------------|---|
| ✓ circuitBreakerTripped | Indicates that the circuit breaker has tripped |
| ✓ leakageDetected | Indicates that an earth leakage fault has been detected. |
| ✓ localOverride | Indicates that there is a local override (ON, OFF) or no override |
| ✓ switchingErrorOff | Indicates error in switching circuit. For instance, if a contactor or relay is used, it may be stuck in OFF position. |
| ✓ switchingErrorOn | Indicates error in switching circuit. For instance, if a contactor or relay is used, it may be stuck in ON position. |

Noise Monitoring Sensor*

This sensor function enables monitoring basic noise data.

Attributes

| # | Attribute | Description |
|---|-----------------------|---|
| ✓ | noiseHighThreshold | Threshold above which a noiseTooHigh event is triggered. (dB) |
| ✓ | noise | Output noise. (dB) |
| ✓ | noiseTooHigh | Indicates the output noise is above the noiseHighThreshold. |
| ✓ | applicationType | Application Type of the noise depending on the use case. E.g.: 'Street noise sensor' |
| ✓ | minMeasuredNoise | The minimum value measured by the sensor since power ON or since measuredNoiseSince. (dB) |
| ✓ | maxMeasuredNoise | The maximum value measured by the sensor since power ON or since measuredNoiseSince. (dB) |
| ✓ | measuredNoiseSince | Indicates the date and time at which measuredNoise is reset to zero. The Gateway may change this value with the actual one depending on implementation. |
| ✓ | abnormalNoiseDetected | Indicates that an abnormal noise is detected |
| ✓ | typeOfNoise | Indicates the type of sound of the abnormalNoiseDetected event. E.g.: gunShot, alarm, carCrash, .. |

Events

| # | Event type | Description |
|---|-----------------------|---|
| ✓ | abnormalNoiseDetected | Indicates that an abnormal noise is detected |
| ✓ | noiseTooHigh | Indicates the output noise is above the noiseHighThreshold. |

Atmospheric Sensor*

This sensor function enables monitoring basic atmospheric data such as barometric pressure, humidity, and temperature. This function complies with WMO standards as reported in the 'Guide to Instruments and Methods of Observation (WMO-No. 8) / Volume I - Measurement of Meteorological Variables'

Attributes

| # | Attribute | Description |
|---|----------------------|---|
| ✓ | airTemperature | Temperature (°C) |
| ✓ | feelsLikeTemperature | Feels like temperature, which take into account the cooling and heating effects of wind and humidity on the human body (°C) |
| ✓ | relativeHumidity | Relative humidity (%) |
| ✓ | dewPoint | Temperature of dew point (°C) |
| ✓ | atmosphericPressure | Atmospheric pressure normalized to sea level (hPa) |
| ✓ | applicationType | Application Type of the atmospheric sensor depending on the use case. E.g.: 'Weather atmospheric sensor' |

Wind Sensor*

This sensor function enables monitoring wind speed and direction. This function complies with WMO standards as reported in the 'Guide to Instruments and Methods of Observation (WMO-No. 8) / Volume I - Measurement of Meteorological Variables'

Attributes

| # | Attribute | Description |
|---|---------------------|---|
| ✓ | windSpeed | Wind speed (m/s) |
| ✓ | windDirectionString | Wind direction (N, NE, E, SE, S, SW, W, NW) |
| ✓ | windDirection | Wind direction in degrees (Relative to True north) |
| ✓ | windGust | Wind gust speed (m/s) |
| ✓ | windGustDirection | Wind gust direction in degrees (Relative to True north) |
| ✓ | maxWindGust | Max wind gust speed (m/s) measured since maxWindGustSince |
| ✓ | maxWindGustSince | Indicates the date and time at which maxWindGust is reset to zero. The Gateway may change this value with the actual one depending on implementation. |
| ✓ | applicationType | Application Type of the wind sensor depending on the use case. E.g.: 'Weather wind sensor' |

Precipitation Sensor*

This sensor function enables monitoring precipitation, defined as the liquid or solid products of the condensation of water vapour falling from clouds, in the form of rain, drizzle, snow, snow grains, snow pellets, hail and ice pellets; or falling from clear air in the form of diamond dust. This function complies with WMO standards as reported in the 'Guide to Instruments and Methods of Observation (WMO-No. 8) / Volume I - Measurement of Meteorological Variables'

Attributes

| # | Attribute | Description |
|---|-------------------------------|--|
| ✓ | precipitationRate | Intensity of precipitation (mm/h) |
| ✓ | accumulatedPrecipitation | Accumulated precipitation since accumulatedPrecipitationSince |
| ✓ | accumulatedPrecipitationSince | Indicates the date and time at which accumulatedPrecipitation is reset to zero. The Gateway may change this value with the actual one depending on implementation. |
| ✓ | applicationType | Application Type of the precipitation sensor depending on the use case. E.g.: 'Weather precipitation sensor' |

Sky Sensor*

This sensor function enables monitoring of other atmospheric phenomena. This function complies with WMO standards as reported in the 'Guide to Instruments and Methods of Observation (WMO-No. 8) / Volume I - Measurement of Meteorological Variables'

Attributes

| # | Attribute | Description |
|---|----------------------|--|
| ✓ | cloudiness | Cloud cover of the sky (%) |
| ✓ | solarDirectRadiation | Total solar irradiance (W/m2) |
| ✓ | visibility | Visibility (m) |
| ✓ | applicationType | Application Type of the sky sensor depending on the use case. E.g.: 'Weather sky sensor' |

Gully Sensor*

The Gully Sensor measures properties associated with street drains or gullies.

Attributes

| # | Attribute | Description |
|---|-----------------|---|
| ✓ | overfull | Indicates that the gully is overfull |
| ✓ | levelWarning | Indicates that the water level is problematic. |
| ✓ | grillOpened | Indicates that the gully grill is opened |
| ✓ | siltLevel | Level of silt (%) |
| ✓ | applicationType | Application Type of the gully sensor depending on the use case. E.g.: 'Street Gully sensor' |

Events

| # | Event type | Description |
|---|------------|-------------|
|---|------------|-------------|

| | | |
|---|--------------|--|
| ✓ | grillOpened | Indicates that the gully grill is opened |
| ✓ | levelWarning | Indicates that the water level is problematic. |
| ✓ | overfull | Indicates that the gully is overfull |

Water Flow Sensor*

The water flow sensor function measures the water flow rate.

Attributes

| # | Attribute | Description |
|---|--------------------------|---|
| ✓ | flowRate | Rate of water flow (m3/s) |
| ✓ | flowRateTooHighThreshold | Threshold above which a flowRateTooHigh event is triggered (m3/s). |
| ✓ | flowRateTooLowThreshold | Threshold below which a flowRateTooLow event is triggered (m3/s). |
| ✓ | flowRateTooHigh | Indicates the flowRate measure is above the flowRateTooHighThreshold. |
| ✓ | flowRateTooLow | Indicates the flowRate measure is below the flowRateTooLowThreshold. |
| ✓ | maxFlowRate | Max flow rate value since flowRateSince (m3/s). |
| ✓ | minFlowRate | Min flow rate value since flowRateSince (m3/s). |
| ✓ | flowRateSince | Sets the date and time at which max and min flow rates are reset to zero |
| ✓ | applicationType | Application Type of the water flow sensor depending on the use case. E.g.: 'Street water flow sensor' |

Events

| # | Event type | Description |
|---|-----------------|---|
| ✓ | flowRateTooHigh | Indicates the flowRate measure is above the flowRateTooHighThreshold. |
| ✓ | flowRateTooLow | Indicates the flowRate measure is below the flowRateTooLowThreshold. |

Water Quality Sensor*

The water quality sensor function measures the quality of the water in the drinkable water distribution network, in water tanks or in lakes and rivers.

Attributes

| # | Attribute | Description |
|---|-----------|---|
| ✓ | pH | Current or last value of the pH measured by the sensor. |

| | |
|----------------------------|---|
| ✓ chlorine | Current or last value of the chlorine measured by the sensor (ppm) |
| ✓ orp | Current or last value of the oxidation reduction potential (ORP) measured by the sensor (V) |
| ✓ totalDissolvedGas | Current or last value of the dissolved gas (TDG) measured by the sensor (ppm). |
| ✓ dissolvedOxygen | Current or last value of the dissolved oxygen measured by the sensor (ppm). |
| ✓ turbidity | Current or last value of the turbidity measured by the sensor using the Nephelometric Turbidity Unit (NTU). |
| ✓ conductivity | Current or last value of the conductivity measured by the sensor (S/m). |
| ✓ conductance | Current or last value of the conductance measured by the sensor (S/m). |
| ✓ totalSuspendedSolids | Current or last value of the TSS measured by the sensor (mg/l). |
| ✓ totalDissolvedSolids | Current or last value of the TDS measured by the sensor (mg/l). |
| ✓ salinity | Current or last value of the salinity measured by the sensor (ppt). |
| ✓ NO3 | Current or last value of NO3 measured by the sensor (mg/l). |
| ✓ NH3 | Current or last value of NH3 measured by the sensor (mg/l). |
| ✓ NH4 | Current or last value of NH4 measured by the sensor (mg/l). |
| ✓ pHTooHigh | Indicates the pH measure is above the pHTooHighThreshold. |
| ✓ pHTooLow | Indicates the pH measure is below the pHTooLowThreshold. |
| ✓ pHTooHighThreshold | Threshold above which a pHTooHigh event is triggered. |
| ✓ pHTooLowThreshold | Threshold below which a pHTooLow event is triggered. |
| ✓ chlorineTooHigh | Indicates the chlorine measure is above the chlorineTooHighThreshold. |
| ✓ chlorineTooHighThreshold | Threshold above which a chlorineTooHigh event is triggered. (ppm) |

| | |
|--|---|
| ✓ orpTooLow | Indicates the orp measure is below the orpTooLowThreshold. |
| ✓ orpTooLowThreshold | Threshold below which a orpTooLow event is triggered. (V) |
| ✓ totalDissolvedGasTooHigh | Indicates the totalDissolvedGas measure is above the totalDissolvedGasTooHighThreshold. |
| ✓ totalDissolvedGasTooLow | Indicates the totalDissolvedGas measure is below the totalDissolvedGasTooLowThreshold. |
| ✓ totalDissolvedGasTooHighThreshold | Threshold above which a totalDissolvedGasTooHigh event is triggered. |
| ✓ totalDissolvedGasTooLowThreshold | Threshold below which a totalDissolvedGasTooLow event is triggered. |
| ✓ dissolvedOxygenTooLow | Indicates the dissolvedOxygen measure is below the dissolvedOxygenTooLowThreshold. |
| ✓ dissolvedOxygenTooLowThreshold | Threshold below which a dissolvedOxygenTooLow event is triggered. |
| ✓ turbidityTooHigh | Indicates the turbidity measure is above the turbidityTooHighThreshold. |
| ✓ turbidityTooHighThreshold | Threshold above which a turbidityTooHigh event is triggered. (NTU) |
| ✓ conductivityTooHigh | Indicates the conductivity measure is above the conductivityTooHighThreshold. |
| ✓ conductivityTooHighThreshold | Threshold above which a conductivityTooHigh event is triggered. (S/m) |
| ✓ conductanceTooHigh | Indicates the conductance measure is above the conductanceTooHighThreshold. |
| ✓ conductanceTooHighThreshold | Threshold above which a conductanceTooHigh event is triggered. (S/m) |
| ✓ totalSuspendedSolidsTooHigh | Indicates the totalSuspendedSolids measure is above the totalSuspendedSolidsTooHighThreshold. |
| ✓ totalSuspendedSolidsTooHighThreshold | Threshold below which a totalSuspendedSolidsTooHigh event is triggered. (mg/l) |
| ✓ totalDissolvedSolidsTooHigh | Indicates the totalDissolvedSolids measure is above the totalDissolvedSolidsTooHighThreshold. |
| ✓ totalDissolvedSolidsTooHighThreshold | Threshold below which a totalDissolvedSolidsTooHigh event is triggered. (mg/l) |
| ✓ salinityTooHigh | Indicates the salinity measure is above the salinityTooHighThreshold. |

| | |
|----------------------------|--|
| ✓ salinityTooLow | Indicates the salinity measure is below the salinityTooLowThreshold. |
| ✓ salinityTooHighThreshold | Threshold above which a salinityTooHigh event is triggered. |
| ✓ salinityTooLowThreshold | Threshold below which a salinityTooLow event is triggered. |
| ✓ NO3TooHigh | Indicates the NO3 measure is above the NO3TooHighThreshold. |
| ✓ NO3TooHighThreshold | Threshold above which a NO3TooHigh event is triggered. (mg/l) |
| ✓ NH3TooHigh | Indicates the NH3 measure is above the NH3TooHighThreshold. |
| ✓ NH3TooHighThreshold | Threshold above which a NO3TooHigh event is triggered. (mg/l) |
| ✓ NH4TooHigh | Indicates the NH4 measure is above the NH4TooHighThreshold. |
| ✓ NH4TooHighThreshold | Threshold above which a NH4TooHigh event is triggered. (mg/l) |
| ✓ applicationType | Application Type of the water quality sensor depending on the use case. E.g.: 'River water quality sensor' |

Events

| # | Event type | Description |
|---|-----------------------|--|
| ✓ | chlorineTooHigh | Indicates the chlorine measure is above the chlorineTooHighThreshold. |
| ✓ | conductanceTooHigh | Indicates the conductance measure is above the conductanceTooHighThreshold. |
| ✓ | conductivityTooHigh | Indicates the conductivity measure is above the conductivityTooHighThreshold. |
| ✓ | dissolvedOxygenTooLow | Indicates the dissolvedOxygen measure is below the dissolvedOxygenTooLowThreshold. |
| ✓ | NH3TooHigh | Indicates the NH3 measure is above the NH3TooHighThreshold. |
| ✓ | NH4TooHigh | Indicates the NH4 measure is above the NH4TooHighThreshold. |
| ✓ | NO3TooHigh | Indicates the NO3 measure is above the NO3TooHighThreshold. |
| ✓ | orpTooLow | Indicates the orp measure is below the orpTooLowThreshold. |

| | |
|-------------------------------|---|
| ✓ pHTooHigh | Indicates the pH measure is above the pHTooHighThreshold. |
| ✓ pHTooLow | Indicates the pH measure is below the pHTooLowThreshold. |
| ✓ salinityTooHigh | Indicates the salinity measure is above the salinityTooHighThreshold. |
| ✓ salinityTooLow | Indicates the salinity measure is below the salinityTooLowThreshold. |
| ✓ totalDissolvedGasTooHigh | Indicates the totalDissolvedGas measure is above the totalDissolvedGasTooHighThreshold. |
| ✓ totalDissolvedGasTooLow | Indicates the totalDissolvedGas measure is below the totalDissolvedGasTooLowThreshold. |
| ✓ totalDissolvedSolidsTooHigh | Indicates the totalDissolvedSolids measure is above the totalDissolvedSolidsTooHighThreshold. |
| ✓ totalSuspendedSolidsTooHigh | Indicates the totalSuspendedSolids measure is above the totalSuspendedSolidsTooHighThreshold. |
| ✓ turbidityTooHigh | Indicates the turbidity measure is above the turbidityTooHighThreshold. |

Text Display Actuator*

The Text Display Actuator is used to send text to a text-only or text mode graphics display within a PositionedTextState (text, xPos, yPos). Writing a string of text to the text resource causes it to be displayed at the selected X and Y locations on the display. If X or Y are set to a value greater than the size of the display, the position "wraps around" to the modulus of the setting and the display size. Likewise, if the text string overflows the display size, the text "wraps around" and displays on the next line down or, if the last line has been written, wraps around to the top of the display. Brightness and Contrast controls are provided to allow control of various display types including STN and DSTN type LCD character displays. Setting the clearDisplay to true causes the display to be erased.

Attributes

| # | Attribute | Description |
|---|-----------------|--|
| ✓ | defaultState | Sets the default state output for the text display actuator. This shall be applicable if the actuator is not under any scheduled (calendarID) or override control (OverrideCommand). |
| ✓ | actualState | This attribute should reflect the physical state of the source as much as possible. It may be calculated or measured, depending on the specific ODN implementation, which is outside the scope of this specification. |
| ✓ | targetCommand | Latest command for the text display actuator. |
| ✓ | feedbackCommand | This attribute reflects the command in effect and it might deviate from the actualState due to propagation time, due to scheduler specific or due to internal ODN specific mechanisms to handle the priority of the requests or response time. |
| ✓ | stateChange | This attribute reflects that the state has changed |

| | |
|-----------------------|---|
| ✓ calendarID | TALQ Address of the calendar controlling this text display actuator. If this attribute is empty, the behavior shall be determined by the ODN. If the attribute is invalid, the ODN shall trigger a generic invalid address event and the behavior shall be determined by the ODN. |
| ✓ invalidCalendar | This attribute reflects that a calendar has been allocated and can not be implemented it. |
| ✓ invalidProgram | This attribute reflects that a control program has been allocated and can not be implemented it |
| ✓ programChange | This attribute reflects that the control program applicable to the actuator has changed. |
| ✓ calendarChange | This attribute reflects that the calendar applicable to the actuator has changed. |
| ✓ targetCommandChange | This attribute reflects that the targetCommand has changed. |
| ✓ applicationType | Application Type of the text display actuator depending on the use case. E.g.: "Traffic Panel" |
| ✓ maxXCoordinate | The highest X coordinate the display supports before wrapping to the next line |
| ✓ maxYCoordinate | The highest Y coordinate the display supports before wrapping to the next line |
| ✓ level | Used to represent a level control such as audio volume, integer value between 0 and 100 as percentage |
| ✓ contrast | Proportional control, integer value between 0 and 100 as percentage |
| ✓ clearDisplay | Command to clear the display |

Events

| # | Event type | Description |
|---|---------------------|---|
| ✓ | calendarChange | This attribute reflects that the calendar applicable to the actuator has changed. |
| ✓ | invalidCalendar | This attribute reflects that a calendar has been allocated and can not be implemented it. |
| ✓ | invalidProgram | This attribute reflects that a control program has been allocated and can not be implemented it |
| ✓ | programChange | This attribute reflects that the control program applicable to the actuator has changed. |
| ✓ | stateChange | This attribute reflects that the state has changed |
| ✓ | targetCommandChange | This attribute reflects that the targetCommand has changed. |

Parking Sensor

The parking sensor provides actual and accumulated occupancy duration as well as forbidden parking detection.

Attributes

| # | Attribute | Description |
|---|---------------------------|---|
| ✓ | occupancy | Status of the parking spot from the point of view of occupancy. Enum: 'closed, vacant, occupied, partially occupied, unknown' |
| ✓ | duration | Number of seconds since the parking place is occupied. If not occupied, duration shows the duration of the last occupation. |
| ✓ | accumulatedDuration | Accumulated occupation time since accumulatedSince. In seconds. |
| ✓ | accumulatedSince | Indicates the date and time at which accumulatedDuration is reset to zero. The Gateway may change this value with the actual one depending on implementation. |
| ✓ | forbiddenParkingDetected | Indicates if the vehicle present on the parking place is not authorized. Set to false if the place is free or if the vehicle is authorized. |
| ✓ | applicationType | Application Type of the parking sensor depending on the use case. E.g.: "Street parking" |
| ✓ | sensorType | Type of sensor (e.g.: IR, PIR, AIR, MR) |
| ✓ | occupancyChangeToVacant | Indicates that the occupancy has changed to vacant |
| ✓ | occupancyChangeToOccupied | Indicates that the occupancy has changed to occupied |
| ✓ | overstayDetected | Indicates if the occupancy duration is over the maxDuration |
| ✓ | maxDuration | Max number of seconds for a parking session. |

Events

| # | Event type | Description |
|---|---------------------------|---|
| ✓ | forbiddenParkingDetected | Indicates if the vehicle present on the parking place is not authorized. Set to false if the place is free or if the vehicle is authorized. |
| ✓ | occupancyChangeToOccupied | Indicates that the occupancy has changed to occupied |
| ✓ | occupancyChangeToVacant | Indicates that the occupancy has changed to vacant |
| ✓ | overstayDetected | Indicates if the occupancy duration is over the maxDuration |

Parking Camera Sensor

The Parking Camera Sensor provides information about the parking slots that only computer vision can provide.

Attributes

| # | Attribute | Description |
|---|----------------------------|---|
| ✓ | totalSlots | Total number of slots monitored by the device. |
| ✓ | slotsData | Data of each slot. |
| ✓ | freeSlots | Number of free slots on the monitored area. |
| ✓ | freeSlotIDs | Ids of the free slots |
| ✓ | averageDuration | Average occupation time per vehicle since accumulatedSince. |
| ✓ | accumulatedParkingSessions | Number of parking sessions since accumulatedSince |
| ✓ | accumulatedSince | Indicates the date and time at which accumulatedParkingSessions and averageDuration are reset to zero. The Gateway may change this value with the actual one depending on implementation. |
| ✓ | forbiddenVehicleDetected | Indicates if there is a vehicle present on the parking slots which is not authorized. Set to false if all the places are free or all the vehicles are authorized. |
| ✓ | blockingVehicleDetected | Indicates if a vehicle is blocking other |
| ✓ | badParkingDetected | Indicates if a vehicle is badly parked (i.e: occupying two slots). |
| ✓ | applicationType | Application Type of the parking camera sensor depending on the use case. E.g.: "Parking Camera" |
| ✓ | zoneReference | Reference of the zone monitored depending on the use case. E.g.: "Zone A1" |

Events

| # | Event type | Description |
|---|--------------------------|---|
| ✓ | badParkingDetected | Indicates if a vehicle is badly parked (i.e: occupying two slots). |
| ✓ | blockingVehicleDetected | Indicates if a vehicle is blocking other |
| ✓ | forbiddenVehicleDetected | Indicates if there is a vehicle present on the parking slots which is not authorized. Set to false if all the places are free or all the vehicles are authorized. |

Luminaire Asset

This entity contains the managed and tracked attributes of a specific Luminaire, excluding the concept of Controller and Driver.

Attributes

| # | Attribute | Description |
|---|---------------------------|--|
| ✓ | luminaireTypeAddress | Address of the Luminaire Type |
| ✓ | bracketTypeAddress | Address of the Bracket Type |
| ✓ | serial | Serial number of the Luminaire |
| ✓ | projectId | Name of the Project / Tender |
| ✓ | luminousFluxConfiguration | Programmed light output of the luminaire |
| ✓ | paintingColor | Painting color of the luminaire expressed as a color system-color value, (e.g: RAL-7035) |
| ✓ | virtualPowerOutput | Percentage of nominal power at which the light source should be set when the Command is set to 100%. |
| ✓ | installationTimestamp | Installation date and time of luminaire |
| ✓ | identification | Luminaire identification. (e.g: as per DiiA/D4i specification part 251 (MB1 extension)). |
| ✓ | identificationNumber | Luminaire identification number. (e.g: as per DiiA/D4i specification part 251 (MB1 extension)) |
| ✓ | mountingOption | Installed direction of the luminaire to the support |
| ✓ | warrantyExpirationDate | Warranty expiration date. It can be reset |
| ✓ | manufactureYear | Year of manufacture of the luminaire. |
| ✓ | manufactureWeek | Week of manufacture of the luminaire. |
| ✓ | warrantyYears | Number of years for warranty |
| ✓ | applicationType | Application Type of the luminaire asset depending on the use case. |

| Driver Asset | | |
|--|------------------------|---|
| This entity contains the managed and tracked attributes of a specific driver | | |
| Attributes | | |
| # | Attribute | Description |
| ✓ | driverTypeAddress | Address of the Driver Type |
| ✓ | serial | Serial number of the driver |
| ✓ | projectId | Name of the Project / Tender |
| ✓ | firmwareVersion | Version of the driver hardware firmware |
| ✓ | installationTimestamp | Installation date and time of driver |
| ✓ | manufactureYear | Year of manufacture of the driver |
| ✓ | manufactureWeek | Week of manufacture of the driver. |
| ✓ | warrantyExpirationDate | Warranty expiration date. It can be reset |

- ☒ applicationType
- Application Type of the driver asset depending on the use case.

Controller Asset

This entity contains the managed and tracked attributes of a specific controller

Attributes

| # | Attribute | Description |
|-------------------------------------|------------------------|---|
| <input checked="" type="checkbox"/> | controllerTypeAddress | Address of the Controller Type |
| <input checked="" type="checkbox"/> | serial | Serial number of the Controller |
| <input checked="" type="checkbox"/> | firmwareVersion | Version of the controller hardware firmware |
| <input checked="" type="checkbox"/> | installationTimestamp | Installation date and time of OLC |
| <input checked="" type="checkbox"/> | registrationTimestamp | Registration date and time of OLC |
| <input checked="" type="checkbox"/> | projectID | Name of the Project / Tender |
| <input checked="" type="checkbox"/> | controllerColor | Painting color of the controller expressed as a color system-color value, (e.g: RAL-7035) |
| <input checked="" type="checkbox"/> | connectionType | Type of the connection to the luminaire |
| <input checked="" type="checkbox"/> | warrantyExpirationDate | Warranty expiration date. It can be reset |
| <input checked="" type="checkbox"/> | manufactureYear | Year of manufacture of the controller |
| <input checked="" type="checkbox"/> | manufactureWeek | Week of manufacture of the controller |
| <input checked="" type="checkbox"/> | applicationType | Application Type of the controller asset depending on the use case. |

Services

Configuration Service

The TALQ Configuration Service enables discovery and configuration of devices and services

Options

| # | Option | Value | Description |
|-------------------------------------|-----------------------------|-------|---|
| <input checked="" type="checkbox"/> | commissioningSupported* | | This ODN can support commissioning from the CMS side. |
| <input checked="" type="checkbox"/> | devicesPaginationSupported* | | This ODN can support pagination of devices. |

Control Service

The Control service describes the mechanisms to operate the actuator functions in order to enable schedule based and override control

Options

| # | Option | Value | Description |
|---|--------------------------|--|--|
| ✓ | supportedTypes | <ul style="list-style-type: none">AbsoluteActivePeriodAstroClockActivePeriodAstroClockTimeControl*DynamicControl*SensorActivePeriod*AstroAndSensorActivePeriod*ExternalControlEffect*FixedControlEffect*ccDate*ccDay* | Control Program and calendar options supported are defined by announcing support for the given modes |
| ✓ | ccDateSupport | | Indicates the ccDate options supported |
| ✓ | ccDaySupport | | Indicates the ccDay options supported |
| ✓ | effectOperationsSupport | <ul style="list-style-type: none">setminmaxaddsubmul | Indicates the dynamic control effect operations supported |
| ✓ | programSecondsSupported* | | Indicates whether the field of seconds is supported in programs. |

Events

| # | Event Type | Description |
|---|-----------------|--|
| ✓ | invalidCalendar | An invalid calendar has been provided by the CMS to the ODN |
| ✓ | invalidProgram | A control program has been provided by the CMS, which cannot be implemented by the ODN |

Data Collection Service

The TALQ Data Collection Service is a provision to configure how ODN measurements, status information and events are logged, and when or under what conditions the logged data is transferred to the CMS

Options

| # | Option | Value | Description |
|---|--------|-------|-------------|
|---|--------|-------|-------------|

| | | |
|---------------------------|--|---|
| ✓ supportedModes | <ul style="list-style-type: none">• EventRecordingMode• PeriodicRecordingMode• VendorRecordingMode• ImmediateReportingMode• ScheduledReportingMode | Recording and Reporting modes supported |
| ✓ samplingPeriodSupported | | Indicates whether the ODN supports periodic sampling for a data logger in periodic recording mode |

Events

| # | Event Type | Description |
|---|---------------------|--|
| ✓ | invalidLoggerConfig | The CMS has provided a data logger configuration that cannot be implemented by the ODN |

On Demand Data Request Service

This service provides the mechanism to access attributes in the logical devices by requesting attribute values from the ODN

Group Management Service

This service provides the mechanisms to define and manage groups

Options

| # | Option | Value | Description |
|---|--------|-------|-------------|
|---|--------|-------|-------------|

Data Package Transfer Service*

This service provides a mechanism to transfer data packages containing ODN vendor specific information to the Gateway via the CMS

Events

| # | Event Type | Description |
|---|----------------------|---|
| ✓ | releaseMismatch | The release indicated as expected does not match the actual release of the Gateway. |
| ✓ | changeReleaseFailure | Change release failed. Operation is rolled back. |
| ✓ | packageChangeFailure | A Package change operation failed. Operation is rolled back. |
| ✓ | changingRelease | Indicates the Gateway is in the process of changing release. |
| ✓ | packageDownloaded | Indicate the Gateway has downloaded a package. |

| |
|--|
| Asset Management Service |
| The TALQ Asset Management Service provides a mechanism to transfer the types needed by the asset management functions |
| Test Service |
| This service provides a mechanism to reduce the human intervention during the certification tests, enabling the certification tests to maximise automation |

Objects

Luminaire Type

The LuminaireType consists of a set of attributes that together characterize, i.e.: are generic for, a given luminaire, excluding the concept of Controller, Driver and Bracket.

Properties

| # | Property | Description |
|---|---------------------------|---|
| ✓ | address | TALQ address of the Luminaire Type |
| ✓ | name | Descriptive name of the LuminaireType |
| ✓ | gtin | Global Trade Item Number of luminaire |
| ✓ | manufacturerName | Name of manufacturer |
| ✓ | productFamily | Product family name of luminaire |
| ✓ | model | Product model of luminaire |
| ✓ | hardwareVersion | Hardware version |
| ✓ | maximumLuminousFluxOutput | Maximum Light Output luminous flux output |
| ✓ | minimumLuminousFluxOutput | Minimum Light Output of the luminaire |
| ✓ | lightSourceType | Light source type. |
| ✓ | lightDistributionType | Enumeration of possible light distribution type, using the Zhaga D4i enumeration. Please refer to ZD4i standard for more details. |
| ✓ | lcsRating | Defines the distribution of light within in three primary solid angles. (LCS: Luminaire Classification System for outdoor luminaires for TM 15 - 11 standard.). E.g: F6-33-19-1, B6-26-10-1, U0-0. |
| ✓ | lightPhotometry | Reference to the photometry of the manufacturer. IES LDT file (e.g. DN08) |

| | |
|--------------------------|---|
| ✓ driverReplaceable | Informs if the driver is replaceable with values: On site, Workshop, No replaceable |
| ✓ lightSourceReplaceable | Informs if the light source is replaceable with values: On site, Workshop and No replaceable |
| ✓ corrosionClass | Extra protection layer against corrosion environment. To use standard ISO 9223 C1 to C5 (https://www.iso.org/standard/53499.html) |
| ✓ maximumPower | Maximum power that the Luminaire can operate at |
| ✓ powerAtMinimumDimLevel | Power at minimum dim level for the luminaire. |
| ✓ weight | Weight of the luminaire |
| ✓ aerodynamicResistance | Equivalent surface area of the luminaire that is exposed to the wind at 0 degrees inclination. |
| ✓ materialEnclosure | Material of enclosure of the body of the luminaire |
| ✓ materialLightCover | Material of light cover |
| ✓ lightCoverShape | Shape of the luminaire cover |
| ✓ luminaireEfficacy | Efficacy of the luminaire |
| ✓ socketTypes | List of socket pairs types/receptacles and positions of the luminaire. E.g: [NEMA at top, Zhaga at underside and Other at remote] |
| ✓ controlVoltMax | DC voltage that gives the maximum light output in a 1-10V control type. |
| ✓ controlVoltMin | DC voltage that gives the minimum light output in a 1-10V control type. |
| ✓ minLightOutput | Sets the minimum light output under which the lamp actuator will not perform the command. |
| ✓ virtualLightOutput | Sets the light output that the lamp actuator shall consider to be equal to 100%. This scaling factor shall be applied before applying the required control voltage. The light command output shall be scaled using this factors, so that 100% in the light command corresponds to this value before applying CLO and maintenance factors. |
| ✓ daliLedLinear | If set to True indicates the dimming curve is linear for DALI control type (some lamp control gear only use linear). |
| ✓ warmUpTime | Sets the delay after a Switch ON command during which the lamp actuator shall not perform any dimming command. |
| ✓ coolDownTime | Sets the delay after a Switch OFF command during which the lamp actuator shall not perform any Switch ON command.(seconds) |

| | |
|----------------------------|--|
| ✓ lowCurrentThreshold | Level of the luminaire supply current under which the ODN shall detect a currentTooLow event. |
| ✓ highCurrentThreshold | Level of the luminaire supply current above which the ODN shall detect a currentTooHigh event. |
| ✓ highTemperatureThreshold | Temperature above which the temperatureTooHigh event is triggered |
| ✓ maxOperatingHours | Maximum number of operating hours that the lamp is supposed to live with a given specification. This attribute can be used to set the old lamp attributes when the lamp reaches its expected useful life. |
| ✓ powerLightGradient | The ratio of change of light level divided by change in power level, which is the slope of the Light level vs. Power curve. It is assumed that 100% power refers to 100% light output. If this attribute is not specified, the attribute shall be set to 1 as default. |
| ✓ lampPowerTolerance | The number of watts by which the actual lamp power can be in error from the expected lamp power (as defined by the dimming curve and the current dimming level) before a lamp power event (lampPowerTooHigh or lampPowerTooLow) is triggered. |
| ✓ lampPowerHighThreshold | The absolute number of watts above which the absolutLampPowerTooHigh event is triggered |
| ✓ lampPowerLowThreshold | The absolute number of watts below which the absolutLampPowerTooLow event is triggered |
| ✓ powerFactorThreshold | The threshold below which powerFactorTooLow event is triggered |
| ✓ lumenDepreciationCurve | Ordered set of entries (cumulative operating hours, correction factor in %) that form a piece wise linear approximation of the lumen depreciation correction factor curve. The first cumulative hours should be 0 and the last correction factor should be 100%. E.g.: 0 h, 80%; 5000 h, 85%; 10000 h, 90%; 15000 h, 95%; 20000 h, 100%. |
| ✓ cloType | Determines where CLO (Constant Lumen Output) is implemented in the lamp control gear or in the ODN (e.g. control device). This CLO profile is needed even when CLO is implemented by the driver in order to obtain the expected lamp power. |

| | |
|--|--|
| ✓ powerFactorThresholdDimmingCurve | Ordered set of entries (power factor threshold, dim level in %) that form a linear approximation of the power factor threshold vs dimming curve. The first dimming should be 0% and the last 100%. E.g.: 0.65 , 0%; 0.60, 10%; 0.70, 20%; 0.75, 30%; 0.80, 40%; 0.85, 50%; 0.87, 60%; 0.89, 70%; 0.90, 80%; 0.95, 90%; 0.98, 100%. |
| ✓ warrantyYears | Number of years for warranty |
| ✓ lightSourceLedCurrent | LED board current |
| ✓ lightSourceLedVoltage | LED board voltage |
| ✓ lightSourceLedNumber | Number of LEDs |
| ✓ lightSourceGtin | Global Trade Item Number of light source |
| ✓ lightSourceManufacturerName | Name of light source manufacturer |
| ✓ lightSourceProductFamily | Product family name |
| ✓ lightSourceModel | Light source model |
| ✓ lightSourceLedEfficacy | Efficacy of the LED |
| ✓ minimumOperatingTemperature | Minimum environment temperature in which the luminaire can operate |
| ✓ maximumOperatingTemperature | Maximum environment temperature in which the luminaire can operate |
| ✓ commonModeOverVoltageProtection | Common mode over voltage protection |
| ✓ diferentialModeOverVoltageProtection | Diferential mode over voltage protection |
| ✓ electricalIsolationClass | Electrical Isolation class. |

Bracket Type

The BracketType consists of a set of attributes that together characterize, i.e: are generic for, a given Bracket.

Properties

| # | Property | Description |
|---|------------------|---|
| ✓ | address | TALQ address of the Bracket Type |
| ✓ | name | Descriptive name of the Bracket Type |
| ✓ | gtin | Global Trade Item Number of bracket |
| ✓ | manufacturerName | Name of manufacturer |
| ✓ | productFamily | Product family name of bracket |
| ✓ | model | Product model of bracket |
| ✓ | mountingOptions | Different options to mount the luminaire to the support |
| ✓ | mountMinDiameter | Mount minimum diameter of the bracket |

| | |
|-------------------------|--|
| ✓ mountMaxDiameter | Mount maximum diameter of the bracket |
| ✓ tiltMinimum | Minimum horizontal inclination of the bracket (positive and negative value). 0 degree means that it is parallel to the LED board |
| ✓ tiltMaximum | Maximum horizontal inclination of the bracket (only positive value). 0 degree means that it is parallel to the LED board |
| ✓ weight | Weight of the bracket |
| ✓ aerodynamicResistance | Equivalent surface area of the bracket that is exposed to the wind. |

Driver Type

The DriverType consists of a set of attributes that together characterize, i.e. are generic for, a given Driver.

Properties

| # | Property | Description |
|---|---------------------------------|--|
| ✓ | address | TALQ address of the Driver Type |
| ✓ | name | Descriptive name of the Driver Type |
| ✓ | controlElectricalInterfaceTypes | The control electrical interface type of the connector of the driver |
| ✓ | controlInterfaceProtocolTypes | The control interface protocol type of the connector of the driver. |
| ✓ | programInterfaceType | Program interface of the driver |
| ✓ | nominalAcMainsVoltage | Nominal AC mains voltage for the luminaire to operate. |
| ✓ | maxAcMainsVoltage | Max AC mains voltage for the luminaire to operate. |
| ✓ | minAcMainsVoltage | Nominal Min AC mains voltage for the luminaire to operate. |
| ✓ | nominalDcMainsVoltage | Nominal DC mains voltage for the luminaire to operate. |
| ✓ | maxDcMainsVoltage | Max DC mains voltage for the luminaire to operate. |
| ✓ | minDcMainsVoltage | Nominal Min DC mains voltage for the luminaire to operate. |
| ✓ | gtin | Global Trade Item Number of driver |
| ✓ | manufacturerName | Name of driveer manufacturer |
| ✓ | productFamily | Product family name |
| ✓ | model | Driver model |
| ✓ | hardwareVersion | talq.feature.property.DriverType.hardwareVersion.desc |
| ✓ | minOutputCurrent | Min output current |
| ✓ | maxOutputCurrent | Max output current |
| ✓ | minOutputVoltage | Min output voltage |
| ✓ | maxOutputVoltage | Max output voltage |
| ✓ | controlOutputType | Constant voltage or constant current regulated |

| | |
|------------------------|--|
| ✓ dimmingOutputType | Dimming output type |
| ✓ dimmingOutputs | Number of dimming outputs |
| ✓ driverNominalCurrent | The pre-programmed current in the driver, determined also by the LED board |
| ✓ driverNominalVoltage | The pre-programmed voltage in the driver, determined also by the LED board |
| ✓ ratedLifeTime | Rated life time of the driver at the maximum operating temperature of the luminaire. |
| ✓ warrantyYears | Number of years for warranty |

Controller Type

The ControllerType consists of a set of attributes that together characterize, i.e. are generic for, a given Controller.

Properties

| # | Property | Description |
|---|----------------------|---|
| ✓ | address | TALQ address of the Controller Type |
| ✓ | name | Descriptive name of the Controller Type |
| ✓ | gtin | Global Trade Item Number of the controller |
| ✓ | powerConsumption | Expected Power consumption of the controller |
| ✓ | locationPrecision | Accuracy of the location determination |
| ✓ | manufacturerName | Name of manufacturer |
| ✓ | productFamily | Product family name of the controller |
| ✓ | model | Model of the Controller |
| ✓ | warrantyYears | Number of years for warranty |
| ✓ | mechanicalInterfaces | Type of mechanical connection or socket |
| ✓ | electricalInterfaces | The control interface protocol type of the connector of the driver. |
| ✓ | protocols | Type of digital communication of the controller |

Lamp type

The lamp type consists of a set of attributes that together characterize a given lamp and control gear combination. When modelling a Lighting ODN with many luminaires, there are attributes' values that are the same for many lamps, e.g.: the expected consumed power of the lamp and control gear (wattage) would be the same for many lamp monitors. The concept of LampType is created to avoid including the same attributes' values in every lamp monitor and actuator of the same type, for this reason a reference to a lamp type is included in the lamp actuator and lamp monitor functions, as these attributes are required for proper operation of these functions. Thus, the definition of lamp types enables the CMS to efficiently set attributes in many lamp actuators/monitors by just setting the address of the 'lampType' attribute in each function. Lamp types can be

created by both CMS and TALQ Gateway as separate entities. The TALQ Gateway shall announce any lamp type it has to the CMS as part of the initial configuration. In addition to the initial configuration, the TALQ Gateway shall also announce the lamp type whenever it changes. The CMS may also send lamp types to the TALQ Gateway.

Properties

| # | Property | Description |
|---|-------------------------|---|
| ✓ | name | Descriptive name of the lamp type |
| ✓ | address | TALQ Address of the lamp type |
| ✓ | wattage | Expected consumed power of the lamp and control gear |
| ✓ | controlType | Type of control/dimming interface between the lamp actuator function and the control gear or within the control gear in case lamp actuator is embedded in the control gear |
| ✓ | controlVoltMax | DC voltage that gives the maximum light output in a 1-10V control type |
| ✓ | controlVoltMin | DC voltage that gives the minimum light output in a 1-10V control type |
| ✓ | minLightOutput | Sets the minimum light output under which the lamp actuator will not perform the command |
| ✓ | virtualLightOutput | Sets the light output that the lamp actuator shall consider to be equal to 100% |
| ✓ | daliLedLinear | If set to true indicates the dimming curve is linear for DALI control type |
| ✓ | warmUpTime | talq.feature.property.LampType.warmUpTime.desc |
| ✓ | coolDownTime | Sets the delay after a switch OFF command during which the lamp actuator shall not perform any switch ON command |
| ✓ | lowCurrentThreshold | Level of the luminaire RMS supply current under which the ODN shall detect a currentTooLow event |
| ✓ | highCurrentThreshold | Level of the luminaire RMS supply current above which the ODN shall detect a currentTooHigh event |
| ✓ | lowLampVoltageThreshold | Level of lamp voltage (not supply voltage) under which the ODN shall detect a voltageTooLow event. [WARNING: Don't use this attribute as a low supply voltage threshold, use the new LampMonitor.lowSupplyVoltageThreshold introduced by TALQ 2.3.0.] |

| | |
|------------------------------------|--|
| ✓ highLampVoltageThreshold | Level of lamp voltage (not supply voltage) under which the ODN shall detect a voltageTooLow event. [WARNING: Don't use this attribute as a high supply voltage threshold, use the new LampMonitor.highSupplyVoltageThreshold introduced by TALQ 2.3.0.] |
| ✓ highTemperatureThreshold | Temperature above which the temperatureTooHigh event is triggered |
| ✓ maxOperatingHours | Maximum number of operating hours that the lamp is supposed to live with a given specification |
| ✓ powerLightGradient | The ratio of change of light level divided by change in power level |
| ✓ lampPowerTolerance | The number of watts by which the actual lamp power can be in error from the expected lamp power |
| ✓ lampPowerHighThreshold | The absolute number of watts above which the absolutLampPowerTooHigh event is triggered |
| ✓ lampPowerLowThreshold | The absolute number of watts below which the absolutLampPowerTooLow event is triggered |
| ✓ powerFactorThreshold | The threshold below which powerFactorTooLow event is triggered |
| ✓ lumenDepreciationCurve | Set of entries (operating hours, correction factor in %) that form a piece wise linear approximation of the lumen depreciation correction factor curve |
| ✓ cloType | Determines where CLO is implemented in the lamp control gear or in the ODN (e.g. control device) |
| ✓ powerFactorThresholdDimmingCurve | Ordered set of entries (power factor threshold, dim level in %) that form a linear approximation of the power factor threshold vs dimming curve. The first dimming should be 0% and the last 100%. E.g.: 0.65 , 0%; 0.60, 10%; 0.70, 20%; 0.75, 30%; 0.80, 40%; 0.85, 50%; 0.87, 60%; 0.89, 70%; 0.90, 80%; 0.95, 90%; 0.98, 100%. |

Event log data

Event log data contains a single event, with eventType and value, in each single log entry. It also includes information about whether the log denotes the start or end of the event. Furthermore additional information can be added with the info attribute.

Properties

| # | Property | Description |
|---|------------|---|
| ✓ | eventType | Identifier of event reported |
| ✓ | srcAddress | Address of Logical device or function within a logical device which is the source of the event or to which this event applies |

- | | |
|----------------|---|
| ✓ startEndFlag | If the event denotes either the start or end of a ‘special’ period, this flag shall be included |
| ✓ info | a string providing more information on the event |
| ✓ attributes | A sequence of attribute values logged together with the event |

Command

A command defines a type of control action that can be applied to a function. Commands can be generated by a manual override action or by a control program.

Properties

| # | Property | Description |
|---|------------------|---|
| ✓ | state | Light state to be applied to the lamp actuator |
| ✓ | reason | Indicates the command was triggered by override, sensor or control program |
| ✓ | cmsRefId | CMS reference, which can be used for data logging. The cmsRefId in a Command is a free text to be used by the CMS for any purpose, e.g: to differentiate contexts. It is a token that allows the CMS to match client requests to the original notification. |
| ✓ | refAddress | Reference to the source of the command, e.g. sensor or control program |
| ✓ | start | Time when the control action resulting from command shall start. This attribute is used only with override commands to set a time to start an override action. If not specified, the override command starts immediately. |
| ✓ | expiration | Time when the control action resulting from command shall be terminated. This attribute is used only with override commands to set a time to stop an override action. After the expiration of an override command, the system should go back to the state defined by the active control program. If not specified, there is no expiration for the override command. |
| ✓ | rampToLevelTime* | The time (in seconds) taken for the value to ramp to the specified level. The change will be finished rampToLevelTime seconds after: the scheduled time if the change comes from a control program; the reception of the request, or the command.start time attribute, if the change comes from an override command, or; the sensor event is raised if the control is sensor-based. If actions related to one command remain to be completed when a subsequent command is received, the subsequent command shall take precedence. |

- ✓ rampFromLevelTime* The time (in seconds) taken for the value to ramp to the specified level. The change will be finished rampFromLevelTime seconds after: the scheduled time if the change comes from a control program; the reception of the request if the change comes from an override command; expiry of the related command, or; the sensor event is lowered and the hold time subsequently expires if the control is sensor-based. If actions related to one command remain to be completed when a subsequent command is received, the subsequent command shall take precedence.

Group


A group is set of entities that can be addressed by the same group address. Devices and functions within devices can be assigned to a group. A group may also include other groups as members.

Properties

| # | Property | Description |
|---|----------|--|
| ✓ | address | Group address |
| ✓ | members | TALQ Addresses of members of the group |
| ✓ | purpose | Main purpose of the group |

: The Certification Test Tool is designed to provide a high level of confidence that complementary systems can communicate successfully. As both the protocol and the test tool evolve, all mandatory and other core tests are confirmed by comparison with real-life scenarios (plug-fest or similar). Some tests of optional and more peripheral features may not yet have been confirmed in this way; such features are identified with an asterisk ().

This Capability List is based on a certification session performed by the TALQ Certification Tool (v2.5.0-update.1) on 2023-01-26 14:06:32.014 +0100.

 and **TALQ** are trademarks owned by the TALQ Consortium.

 TALQ Consortium

