

Certified Capability List

This Capability List is based on a certification session performed by the *TALQ Certification Tool (v2.4.1-update.12)* on 2023-01-30 19:23:14.503 +0530.

The Capability List is a consolidated list of TALQ features which are implemented in a product.

The tool has succesfully performed 46 tests.

Product details

| Product Name | Ubicquia Gateway | , |
|----------------|------------------|---|
| FIUUUULINAIIIE | Obludula Galeway | / |

Company Ubicquia Inc.

Type GATEWAY

Notes

Generated on 2023-01-30 19:23:14.503 +0530

Supported profiles

Lighting

API version certified: 2.4.1

Certification performed by app version: 2.4.1-update.12

Capability list

Security

Enabled 🗸

about:blank 1/12

Functions

Basic

The Basic function describes the properties related to the physical asset to which the logical device is associated, such as identification (assetId) and location information.

Attributes

| # Attribute | Description |
|-----------------|---|
| displayName | Display name of the asset. |
| ✓ assetId | Customer identifier of the asset. If multiple devices have the same assetId it means they belong to the same asset. |
| ✓ serial | Serial number of the device. |
| ✓ hwType | Hardware type of the device. |
| ✓ hwVersion | Hardware revision of the device. |
| ✓ swVersion | Software version installed on the device. |
| ✓ deviceReset | The physical device containing the logical device was reset. |
| ✓ currentTime | Current time of the device defined as local time with time zone designator. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TimeFunction.currentTime instead.] |

Events

| # | Event type | Description | |
|----------|-------------|---|--|
| ~ | deviceReset | The physical device containing the logical device was reset | |

Communication

The Communication Function contains attributes related to the communication within the ODN, and between ODN devices and Gateways. Although communication within the ODN is outside the scope of the TALQ Smart City Protocol, this Function enables access to a minimum set of configuration and state information of the ODN communication interface in order to facilitate system management from the CMS.

Attributes

about:blank 2/12

| ~ | communicationType | Type of communication technology implemented by the ODN (e.g. power line, wireless). |
|----------|----------------------|--|
| ~ | physicalAddress | Physical address of the device. For example, IEEE MAC address. This attribute can be used to map between logical and physical devices. The format is specific to the ODN implementation. |
| ~ | communicationQuality | Indicator of the quality of the communication with the device. 100% means good quality. |

Events

| # | Event type | Description |
|----------|----------------------|---|
| ~ | communicationFailure | This event is generated by the ODN when the communication function is not operating as expected |

Gateway

The Gateway function includes the necessary attributes to enable the communication between the CMS and the Gateway according to the TALQ Specification.

Attributes

| # | Attribute | Description |
|----------|----------------|--|
| ~ | cmsUri | Base URI for TALQ communication that allows the Gateway to access the CMS. Must be an absolute URI. Other URI's for accessing CMS can be relative to this base. |
| ~ | cmsAddress | CMS UUID address |
| ✓ | gatewayUri | Base URI for TALQ communication that allows the CMS to access the Gateway. Must be an absolute URI. Other URI's for accessing Gateway can be relative to this base. |
| ~ | gatewayAddress | Gateway UUID address |
| ~ | retryPeriod | Time duration before the Gateway retransmits a message for which expected response has not been received. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new GatewayFunction.gatewayRetryPeriod instead.] |
| ~ | crlUrn | URI where the Gateway can obtain the Certification Revocation List (CRL). |
| ~ | vendor | Vendor identification. |

about:blank 3/12

Lamp Actuator

The Lamp Actuator function includes attributes related to lighting control and it represents the smallest unit for control purposes. In practice, however, a Lamp Actuator function can control combinations of several lamps and control gear but all in the same way, as if they are all one individual unit.

Attributes

| # | Attribute | Description |
|----------|----------------------|---|
| ~ | defaultLightState | Sets the default light output for the lamp actuator. This shall be applicable if no other command is active. This attribute shall be set to 100% as default value. |
| ~ | targetLightCommand | Latest command for the lamp actuator. |
| ✓ | feedbackLightCommand | This attribute reflects the command in effect and it might deviate from the actualLightState due to propagation time or due to internal ODN specific mechanisms to handle the priority of the requests. |
| ~ | actualLightState | This attribute should reflect the physical state of the light source as much as possible, including factors such as CLO. It may be calculated or measured, depending on the specific ODN implementation, which is outside the scope of this specification. |
| ✓ | calendarID | TALQ Address of the calendar controlling this lamp actuator. If this attribute is empty, the behavior shall be determined by the ODN. If the attribute is invalid, the ODN shall trigger a generic invalid address event and the behavior shall be determined by the ODN. |

Events

| # | Event type | Description |
|----------|------------------|-------------------------|
| ✓ | lightStateChange | Light state has changed |

Lamp Monitor

The Lamp Monitor function enables monitoring of lamp parameters. A Lamp Monitor function should be associated with a specific lamp/control gear combination. Multiple lamp monitor functions may be implemented by a single device.

Attributes

| # Attribute Description |
|-------------------------|
|-------------------------|

about:blank 4/12

| ✓ switchOnCounter | Cumulative number of ON/OFF cycles since installation of the lamp. The wrap around value is 2e32 - 1. |
|------------------------------|--|
| ✓ operatingHours | Number of hours the lamp is on. This is the value used in CLO and may be set by the CMS. |
| ✓ temperature | Temperature of the device implementing this function. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TemperatureSensorFunction.temperature instead.] |
| ✓ supplyVoltage | RMS supply volts when supplyType is AC, supply voltage (V) when supplyType is DC. |
| ✓ supplyCurrent | RMS supply current (A) when supplyType is AC, supply current (A) when supplyType is DC. |
| ✓ activePower | Active power. |
| ✓ powerFactor | Active power/Apparent power. |
| ✓ lampFailure | The lamp is not operating as it is supposed to (e.g. the lamp is broken). This event shall be used to detect a situation where the lamp (or LED module(s)) should be lit, but produce no light. This could be detected by the current flowing or power consumed. |
| ✓ supplyLoss | Indicates loss of mains power. |
| ✓ highSupplyVoltageThreshold | Supply voltage above which the supplyVoltageTooHigh event is triggered. |
| ✓ lowSupplyVoltageThreshold | Supply voltage below which the supplyVoltageTooLow event is triggered. |

Events

| # | Event type | Description |
|----------|--------------------|--|
| ~ | lampVoltageTooHigh | Level of lamp voltage (not supply voltage) is greater than highLampVoltageThreshold. |
| ~ | lampVoltageTooLow | Level of lamp voltage (not supply voltage) is smaller than lowLampVoltageThreshold. |

about:blank 5/12

| ✓ lampFailure | The lamp is not operating as it is supposed to (e.g. the lamp is broken). This event shall be used to detect a situation where the lamp (or LED module(s)) should be lit, but produce no light. This could be detected by the current flowing or power consumed. |
|---------------|--|
| ✓ supplyLoss | Indicates loss of mains power |

Electrical Meter

The electrical meter function supports electrical metering capabilities including measurements of voltage, current, power, energy, and power factor. This function may be associated with Luminaire Controllers, Cabinet Controllers or electrical meters installed in switch boxes. ODNs may implement both single phase and three phase meters. Typically meters within a control device will be single phase and stand-alone meters. A street side cabinet may have single phase or three phase meters.

Attributes

| # | Attribute | Description |
|----------|-------------------|--|
| ~ | totalPower | Sum of the active power consumed on phase 1, 2 and 3, or just the power for a single phase meter. |
| ~ | frequency | Frequency on the line. |
| ~ | totalPowerFactor | Total active power divided by total apparent power. |
| ~ | phase1PowerFactor | Power factor on phase 1. |
| ~ | supplyVoltage | Average between Phase1 RMS Voltage, Phase2 RMS Voltage and Phase3 RMS Voltage, or in the case of a single phase meter just the RMS supply voltage. |
| ~ | phase1Voltage | RMS Voltage between phase 1 and neutral. |
| ~ | phase1Current | RMS current on phase 1. |
| ~ | phase1ActivePower | Active Power on phase 1. |

Events

Photocell

A Photocell function models the capabilities of a photocell that can be used for lighting control. This function shall be supported by the CMS and optionally by the ODNs (Gateway).

Attributes

about:blank 6/12

| # | Attribute | Description |
|----------|-----------------|--|
| ~ | onLevel | Illuminance level at which the photocell switches to on state. |
| ~ | offLevel | Illuminance level at which the photocell switches to off state. |
| ~ | photocellOutput | Output state of the photocell. Possible values are ON (means the illuminance level has fallen below the onLevel) and OFF (means the illuminance level has risen above the offLevel). |

Events

| # Event type Description | # | Event type | Description |
|--------------------------|---|------------|-------------|
|--------------------------|---|------------|-------------|

Light Sensor

A Light Sensor function models the output of light sensor. This function is optional for both CMS and Gateway, but when supported the requirements in this section shall apply.

Attributes

| # | Attribute | Description |
|----------|------------|--------------------|
| ~ | lightLevel | Illuminance level. |

Events

| # | Event type | Description |
|---|------------|-------------|
| | | |

Location Sensor*

The Location Sensor Function is used to indicate that an object has changed position attributes configurable by the CMS or based on internal setup of the vendor. For example, a specific location (latitude, longitude) of a device could be defined by the vendor. If the device is equipped with a GPS, it could send a specific event indicating that its position is different to the one defined by the CMS. We might also want to let the configuration to the vendor itself and simply define events notifying the CMS that the default configuration has changed. For example, a garbage bin could have its location defined based on a sensor placed on the floor. If the bin is not above this sensor, the vendor will trigger an event. In this last case, the CMS does not need to configure anything.

Attributes

| # | Attribute | Description |
|----------|-----------|------------------------|
| ✓ | location | Location of the device |

| Events | | |
|--------------|-------------|--|
| # Event type | Description | |

about:blank 7/12

✓ locationChanged Triggered when the difference between location and expectedLocation is above locationChangedThreshold

Orientation*

The Orientation function is used to indicate that an object has changed orientation based on attributes configurable by the CMS or based on internal setup of the vendor. The target orientation of the object could be configured by the CMS or could be handled by the vendor. In the latter case, the configuration is let to the vendor itself and events are triggered depending on internal configuration.

Attributes

| # | Attribute | Description |
|----------|-----------------------------|---|
| ~ | orientationChangedThreshold | Threshold above which orientationChanged is triggered |
| / | orientation | Orientation of the device |

Events

| # | Event type | Description |
|----------|--------------------|---|
| ✓ | orientationChanged | Triggered when orientation differs from expectedOrientation by more than orientationChangedThreshold on any angle, or when the device determines itself that its orientation has changed. |

Services

Configuration Service

The TALQ Configuration Service enables discovery and configuration of devices and services

Options

| # | Option | Value | Description |
|----------|-----------------------------|-------|---|
| ~ | commissioningSupported* | | This ODN can support commissioning from the CMS side. |
| ~ | devicesPaginationSupported* | | This ODN can support pagination of devices. |

about:blank 8/12

Control Service

The Control service describes the mechanisms to operate the actuator functions in order to enable schedule based and override control

Options

| # | Option | Value | Description |
|----------|-------------------|--|--|
| ✓ | supportedTypes | AbsoluteActivePerio AstroClockActivePerio AstroClockTimeConx * SensorActivePeriod ccDate* ccDay* | riod and calendar trol options supported are defined by |
| ✓ | programSecond | sSupported* | Indicates whether the field of seconds is supported in programs. |
| Eve | ents | | |
| # | Event Type | Description | |
| ~ | invalidCalendar | An invalid calendar has been provided b | y the CMS to the ODN |

✓ invalidProgram A control program has been provided by the CMS, which cannot

be implemented by the ODN

Data Collection Service

The TALQ Data Collection Service is a provision to configure how ODN measurements, status information and events are logged, and when or under what conditions the logged data is transferred to the CMS

Options

| # Event Type Description |
|--------------------------|
|--------------------------|

about:blank

✓ invalidLoggerConfig The CMS has provided a data logger configuration that cannot be implemented by the ODN

On Demand Data Request Service

This service provides the mechanism to access attributes in the logical devices by requesting attribute values from the ODN

Test Service

This service provides a mechanism to reduce the human intervention during the certification tests, enabling the certification tests to maximise automation

Objects

Lamp type

The lamp type consists of a set of attributes that together characterize a given lamp and control gear combination. When modelling a Lighting ODN with many luminaires, there are attributes' values that are the same for many lamps, e.g.: the expected consumed power of the lamp and control gear (wattage) would be the same for many lamp monitors. The concept of LampType is created to avoid including the same attributes' values in every lamp monitor and actuator of the same type, for this reason a reference to a lamp type is included in the lamp actuator and lamp monitor functions, as these attributes are required for proper operation of these functions. Thus, the definition of lamp types enables the CMS to efficiently set attributes in many lamp actuators/monitors by just setting the address of the 'lampType' attribute in each function. Lamp types can be created by both CMS and TALQ Gateway as separate entities. The TALQ Gateway shall announce any lamp type it has to the CMS as part of the initial configuration. In addition to the initial configuration, the TALQ Gateway shall also announce the lamp type whenever it changes. The CMS may also send lamp types to the TALQ Gateway.

Properties

| # Property | Description |
|---------------|--|
| ✓ name | Descriptive name of the lamp type |
| ✓ address | TALQ Address of the lamp type |
| ✓ controlType | e Type of control/dimming interface between the lamp actuator function and the control gear or within the control gear in case lamp actuator is embedded in the control gear |

about:blank 10/12

Event log data

Event log data contains a single event, with eventType and value, in each single log entry. It also includes information about whether the log denotes the start or end of the event. Furthermore additional information can be added with the info attribute.

Properties

| # | Property | Description |
|----------|------------|---|
| ✓ | eventType | Identifier of event reported |
| ~ | srcAddress | Address of Logical device or function within a logical device which is the source of the event or to which this event applies |

Command

A command defines a type of control action that can be applied to a function. Commands can be generated by a manual override action or by a control program.

Properties

| # Property | Description |
|------------|---|
| ✓ state | Light state to be applied to the lamp actuator |
| ✓ cmsRefld | CMS reference, which can be used for data logging. The cmsRefld in a Command is a free text to be used by the CMS for any purpose, e.g. to differentiate contexts. It is a token that allows the CMS to match client requests to the original notification. |

: The Certification Test Tool is designed to provide a high level of confidence that complementary systems can communicate successfully. As both the protocol and the test tool evolve, all mandatory and other core tests are confirmed by comparison with real-life scenarios (plug-fest or similar). Some tests of optional and more peripheral features may not yet have been confirmed in this way; such features are identified with an asterisk ().

This Capability List is based on a certification session performed by the TALQ Certification Tool (v2.4.1-update.12) on 2023-01-30 19:23:14.503 +0530.

(()) and TALQ are trademarks owned by the TALQ Consortium.

G TALQ Consortium

about:blank 11/12



about:blank